


READ BEFORE USE

Thank you for purchasing our product. Here are some quick instructions for easy use.




1 Remove all Styrofoam, plastic wrappings, cord ties, coverings and the plug cap.

Note: Be sure to not throw away the plastic bag with the remote and manual.




2 Plug the cord into a working dedicated three-prong grounded outlet on the wall. (No surge protectors, powerstrips, or extension cords)



3 Push the Master Power switch (located at the back of the unit) to the "on" position.

Note: Not all units will have a Master Power Switch



4 Push and release the power button on the front control panel.

Note: Your unit will automatically default to a preset temperature. Press the temp up button to raise the temperature at least 3-5 degrees above the default temp to engage heating elements.



5 Listen for the fan to engage. This should take a minute or two.



6 There may be an odor which is the coating burning off of the heating elements. This is normal for the first few uses.



For more detailed information on your product please refer to your owner's manual. For help with your heater contact us Monday – Friday, 8 am – 5 pm CST

Email us: warranty@lifesp.com or Call us: **866-484-2066**
www.lifsmartproducts.com

Model Number: _____ Serial Number: _____

*Note: To better serve you, please be sure to have your model number and serial number ready. Both numbers can be located on the back or side of the unit.

1 YEAR LIMITED MANUFACTURER WARRANTY

KEEP THIS FOR YOUR RECORDS

For help with your heater contact us Monday – Friday 8 am – 5 pm CST

Email us: warranty@lifesp.com or Call us: 866-484-2066

1 Year Limited Warranty: The Manufacturer warrants this heater against defects in materials and workmanship **on functional parts**, for a period of 1 year from the original date of purchase. **Your sales receipt showing the date of purchase of the product is your proof of purchase. Keep it in a safe place for future reference.**

Manufacturer Warranty All products are manufactured with the highest quality materials and are warranted to be free from defects in material and workmanship at the time of purchase. This limited warranty applies to products manufactured or distributed by the manufacturer, are delivered in the continental United States, and extends to the original purchaser, or gift recipient. This warranty becomes valid at the time of purchase and terminates either by the specified time frame listed above and/or owner transfer (unless otherwise authorized, by the manufacturer). Any extended warranties (warranties that cover above and beyond this manufacturer warranty) that are sold through a retailer or third party, are not directly correlated with this limited warranty, and **MUST** be redirected to retailer or third party for coverage.

Extent of Warranty This warranty extends through the manufacturer of the product, and covers functional parts only. Cosmetics are not covered, unless unequivocally determined it is a manufacturer/workmanship defect. Note that surface cracks are not considered defects in material or workmanship, as they are normal characteristics of all wood. Unless the direct shipper, shipping damage should be addressed with the shipping company, retailer, or place of purchase, prior to making a claim, as the manufacturer.

The manufacturer's sole obligation under this warranty shall be limited to furnishing the original purchaser replacement parts for units deemed repairable by the warranty department. The purchaser may also opt to ship the product to have it repaired. The purchaser will be responsible to prepay any shipping charges (both ways), export taxes, custom duties and taxes, or any other charges associated with the transportation of the unit. In addition, the purchaser is responsible for insuring any parts shipped or returned, if desired. For products the warranty department deems un-repairable, or discontinued, the company reserves the right to issue a refurbished product, or product similar in size and functionality as a replacement for the defective unit, **if available**. All exchanged parts and products replaced under this warranty will become the property of the Manufacturer. We reserve the right to change manufacturers of replacement parts or products for use, in order to cover any existing warranty. Any parts determined defective may be asked to be returned to the Manufacturer or its representatives to validate a claim. Non-Warranty replacement parts will be warranted 30 days from the time the purchaser receives them.

The purchaser must present proof of purchase documents (including the date of purchase) if requested. Any evidence of alteration, erasing, or forgery of proof of purchase documents will be just cause to **VOID** this limited warranty.



For more detailed information on your product please refer to your owner's manual. For help with your heater contact us Monday – Friday, 8 am – 5 pm CST

Email us: warranty@lifesp.com or Call us: 866-484-2066
www.lifsmartproducts.com

Model Number: _____ Serial Number: _____

*Note: To better serve you, please be sure to have your model number and serial number ready. Both numbers can be located on the back or side of the unit.