

HOME DECORATORS COLLECTION

James Chair ASSEMBLY INSTRUCTION











Model No: IC-169
HDC#: 0277000250


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to ensure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our customer service department. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST

<p>A</p>  <p>Seat Frame-1pc</p>	<p>B</p>  <p>Leg-1pc</p>	<p>C</p>  <p>Cushion-1pc</p>
<p>D</p>  <p>Allen Wrench-1pc</p>	<p>E</p>  <p>M6*25 Screw-4pcs</p>	<p>F</p>  <p>Connector-4pcs</p>
<p>G</p>  <p>Blind Nut-4pcs</p>	<p>H</p>  <p>Wrench-1pc</p>	


1



Please note the difference between the back and seat. There is two short slats on the seat to be connected to the leg.

Note: Keep the holes of the seat panel and leg in line, use the M6 screw to reinforce only.

2



Fix the cushion to the seat.

Model No:IC-169
HDC#: 0277000250