## IMPORTANT INSTRUCTIONS TO INSTALLER

Inspect the RL Series Fan for shipping damage within 15 days of receipt. Notify Spruce of any damages immediately. Spruce is not responsible for damages incurred during shipping. However, for your benefit, Spruce does insure shipments.

There are no user serviceable parts inside the fan. Do not attempt to open. Return unit to factory for service.

Install the RL Series Fan in accordance with all state and local building codes and state regulations.

