



NB-G110P
**FlashXpress™
 Toaster Oven**

Interior Light

Allows you to view your food while it is cooking.

Hinged Door

A flexible device that allows pivoting of the door.

Digital Timer and Temperature Settings

Lets you control cooking start time so fresh or frozen foods are ready when you are.

Removable Crumb Tray

Convenient removal tray allows for easy cleaning.



Double Infrared Heating (Near & Far)

Instant heat, no preheating necessary! Far infrared heating is used to cook the outside of the food efficiently, where as the Near infrared heating is able to penetrate the food and efficiently cook the inside. The result is more evenly cooked food in a fraction of the time!

Square Shaped Inner Tray

Perfect for pizza up to 9 inches in diameter or four slices of bread.

Accessories

- Drip Rack
- Baking Tray



Auto Cook Menus

With just the press of a button, you can pick from one of the 6 illustrated preset buttons. Automatically calculates the cooking time for a variety of foods:

Cooking Modes

- Toast
- Waffle
- Roll
- Pizza
- Quick
- Hash Brown



More information available at www.panasonic.com/appliances

Model		Design		Features								Power		Dimensions & UPC									
Model Number	Color	Inner Cooking Tray	Heating Element	Pre-set Programming	Light	Drip Rack/Baking Tray	Crumb Tray	Crust Control	Temperature Setting	Digital Timer	Reminder Beep	Power Consumptions	Power Supply	Container Qty. (20 ft.)	Master Pack			Carton		Unit		Country of Origin	UPC
															Qty.	W x D x H (in.)	Gross Weight (lbs.)	W x D x H (in.)	Net Weight (lbs.)	W x D x H (in.)	Unit Weight (in.)		8-85170 -
NB-G110P	Silver	Square, 9" Diameter	Double Infrared (Near/Far)	6	Yes	Yes	Removable	Light / Medium / Dark	250°F - 500°F	Up to 25 minutes	Yes	1300 Watts	120V AC, 60 Hz	784	2	28-3/4 x 26-9/16 x 13-3/16	19.6	14-1/8 x 13 x 12-6/16	9.7	13 x 12 x 10-1/4	7.5	China	09276 - 1