

TRAMONTINA

LIMITED EDITIONS

COPPER CLAD MIXING BOWLS

Use & Care Instructions

Using Your Copper Clad Mixing Bowls

- To preserve the copper finish during transportation and store display, a temporary and transparent coating was applied to the exterior copper surface during manufacturing. Hand-wash only with warm, soapy water this will dissolve the transparent coating. Rinse and dry thoroughly using a nonabrasive cloth.
- To preserve the interior finish of the bowls, we recommend using only silicone, nylon, bamboo or wood utensils. Using metal utensils will scratch the interior surface.
- Do not leave or store food in the mixing bowls for long periods of time. Superficial pitting may occur if very salty or acidic foods (such as tomatoes) are left in the bowls.
- The mixing bowls are not suitable for stove-top, oven or microwave use.



Cleaning and Caring For Your Copper Clad Mixing Bowls

To preserve the beauty and exterior copper finish of the mixing bowls, please follow these cleaning and caring instructions:

- Hand-wash only using a nonabrasive pad. Due to the copper exterior finish, these mixing bowls are not dishwasher-safe. We recommend hand-drying the mixing bowls immediately after hand-washing to preserve the original finish.
- Cooking professionals and enthusiasts desire and prefer kitchenware items with a copper exterior for many reasons, including the rich and unique exterior patina.
- All copper surfaces darken when exposed to air and from use, and will develop a distinctive exterior patina. This is a normal characteristic of kitchenware items with a copper exterior, and does not inhibit the item's performance.
- To recondition the copper exterior to a bright finish, use a nonabrasive cloth and quality copper cleaner, such as Wright's Copper Cream®.

IMPORTANT

- **HAND-WASH ONLY**

Available Copper Clad Mixing Bowl Capacities:

- 1.5 Qt - 1.4 L
- 3 Qt - 2.8 L
- 5 Qt - 4.7 L
- 8 Qt - 7.5 L

Lifetime Warranty

This product is warranted by TRAMONTINA to be free from defects in material and workmanship for the lifetime of the original purchaser. Any piece will be repaired or replaced at no charge with the same item or one of equal or better value if it is found to be defective under normal, noncommercial household use and when cared for according to the manufacturer's instructions. This warranty does not cover lost or stolen items or defects caused by accidents, fire, or abuse or misuse of the products, including but not limited to overheating, improper cleaning with harsh cleansers or detergents, neglect, alteration, or use in commercial establishments.

For repair or replacement, return defective merchandise by package delivery service or insured parcel post with a letter of explanation to the customer service department listed below.

This warranty gives you specific legal rights, and you may also have other rights, which vary according to country, state or province.

Any questions regarding this warranty and/or the use and care of this product should be directed to:

TRAMONTINA

TRAMONTINA USA, Inc.

Customer Service

12955 West Airport Blvd.
Sugar Land, TX 77478-6119
(800) 221-7809

www.tramontina-usa.com

MADE IN CHINA

PACKAGED IN USA

80202/000DS

80202/001DS

80202/002DS

80202/003DS

80202/004DS