



Parts List for CM1640 Type 1

Item Number	Part Number	Description	Qty Required
1	5140149-35	UPPER HANDLE ASSY.	1
2	5140149-62	KEY BOX COMPONENT	1
3	5140149-63	KEY STRAP	1
4	5140149-64	FAST CLIP COMPONENT	1
5	5140149-68	HANDLE BASE	2
6	5140149-69	PLASTIC WASHER	2
7	5140149-70	CLAMP KNOB	2
8	5140149-71	HEX NUT	4
9	5140149-72	HANDLE	1
10	5140149-58	WIRE PIE	1
11	5140149-74	CLIP COMPONENT	1
12	5140149-76	HANDLE	2
13	5140149-77	SELF TAPPING SCREW	48
14	5140149-78	LEFT ADJUST GEAR	1
15	5140149-79	SELF TAPPING SCREW	13
16	5140149-80	LEFT FIXED GEAR	1
17	5140149-81	ADJUSTING SPRING	1
18	5140149-82	WASHER	1
19	5140149-83	BACK COVER BOARD	1
20	5140149-84	RUBBER PLUG	1
21	5140149-85	HOUSING	1
22	5140149-86	TORSION SPRING	1
23	5140149-87	REAR COVER SHAFT	1
24	5140149-88	RIGHT FIXED GEAR	1
25	5140149-89	RIGHT ADJUST GEAR	1
26	5140149-90	LOCK NUT	2
27	5140149-91	SUPPORT PLATE	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for CM1640 Type 1

Item Number	Part Number	Description	Qty Required
28	5140149-92	FIXED PLATE	2
29	5140149-93	GRASSFLAP	1
30	5140149-94	SCREW	2
31	5140149-95	INDICATOR	1
32	5140149-96	HANDLE	1
33	5140149-97	GRASSBOX COVER	1
34	5140149-98	CABLE CLAMP	1
35	5140149-99	GRASSBOX	1
36	5140150-00	SUPPORT	1
37	5140150-01	FAN	1
38	5140150-02	BLADE PLATE	1
39	5140150-03	GRASS PLATE	1
40	5140149-43	SELF TAPPING SCREW	1
41	CMB1600	BLADE	1
41	5140150-05	BLADE	1
42	5140150-06	BLADE CLAMP	1
43	5140150-07	BLADE BOLT	1
44	5140150-08	WHEEL COVER	2
45	5140150-09	LOCK NUT	4
46	5140150-10	WASHER	4
47	5140150-11	REAR WHEEL	2
48	5140150-12	WHEEL SHAFT ASSY.	4
49	5140150-13	REAR AXLE	1
50	5140150-14	WHEEL COVER	2
51	5140150-15	FRONT WHEEL	2
52	5140150-16	FRONT AXLE	1
53	5140150-17	SIDE COVER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for CM1640 Type 1

Item Number	Part Number	Description	Qty Required
54	5140150-18	LOCK NUT	2
55	5140150-19	HEIGHT ADJUSTER	1
56	5140150-26	FLANGE BOLT	2
57	5140150-27	SCREW	1
58	5140150-28	ADJUSTER PLATE	1
59	5140150-29	FLANGE NUT	3
60	5140150-30	CLAMP HANDLE	2
61	5140150-31	SCREW	3
62	5140150-32	GASKET	1
64	5140150-33	SCREW	1
65	5140150-34	CEMENT RESISTANCE	1
66	5140150-35	MOTOR ASSEMBLY	1
67	5140150-36	CIRCUIT BOARD	1
68	5140150-37	CLAMP	1
69	5140150-38	TERMINAL	1
70	5140150-39	TERMINAL	2
71	5140150-40	CONNECTING WIRE	1
72	5140150-41	SELF TAPPING SCREW	4
73	5140150-42	PUSH BUTTON CLAMP	1
74	5140150-43	SWITCH BUTTON	1
75	5140150-44	PUSH BUTTON	1
76	5140150-45	ANTI LOCK SPRING	2
77	5140150-46	COVER	1
79	5140150-47	RUBBER PLUG	1
80	5140150-48	COVER	1
81	5140150-49	BLOCK	1
82	5140150-50	FIXED PLATE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for CM1640 Type 1

Item Number	Part Number	Description	Qty Required
83	5140150-51	FLANGE SCREW	2
84	5140150-98	HANDLE COVER	1
84	5140150-52	HANDLE	1
85	5140150-53	SELF TAPPING SCREW	2
88	5140150-95	BINDING WIRE	7
89	5140161-28	SELF TAPPING SCREW	2
90	5140161-29	FIXED PLATE	2
101	5140171-14	HANDLE ASSEMBLY	1
102	5140171-14	HANDLE ASSEMBLY	1
103	5140149-38	HANDLE COVER	1
104	5140149-39	SWITCH BOX ASSY	1
105	5140149-40	BUTTON	1
106	5140149-41	SPRING	1
107	5140149-42	BUTTON	1
108	5140149-43	SELF TAPPING SCREW	1
109	5140149-44	SWITCH	1
110	5140149-45	SWITCH AND CABLE	1
111	5140149-46	TRIGGER BUTTON	1
112	5140149-47	SELF TAPPING SCREW	4
113	5140149-48	CLAMP	1
114	5140149-49	SELF TAPPING SCREW	8
115	5140149-50	HOOK PLATE	1
116	5140149-51	SCREW	1
117	5140149-52	TORSION SPRING	1
118	5140149-53	GUIDE	1
119	5140149-54	HEX NUT	1
120	5140149-55	CABLE CLAMP	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for CM1640 Type 1

Item Number	Part Number	Description	Qty Required
121	5140149-56	HEAT SHRINK SLEEVE	1
122	5140149-57	CONNECTOR-WIRE	1
123	5140149-58	WIRE PIE	1
124	5140149-59	CABLE	1
125	5140149-60	BUSHING	2
126	5140149-61	CABLE	1
127	5140149-65	SPRING PIN	3
128	5140149-66	CLAMP HANDLE	3
129	5140149-67	CLAMP LEVER	1
130	5140149-75	QUICK CLAMP LEVER	2
131	5140150-20	BAR	1
132	5140150-21	RAISE COMPONENT	1
133	5140150-22	RAISE COMPONENT	1
134	5140150-23	SET SCREW	2
135	5140150-24	LOCK NUT	4
136	5140150-25	BAR	1
177	5140186-18	GRASS BAG	1
178	5140186-19	FRAME,GRASS BAG	1
866	LBXR2036	BATTERY PACK	1
871	90601950N	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.