



OMS THD SKU# 1003 135 593

Model # TY450-1814-1

ASSEMBLY INSTRUCTIONS

40in 105 Light LED DOG

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Please note that many of the parts are connected by the lighting string that runs throughout the item. Remove the parts with care not to damage the lighting string or parts. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return the item to place of purchase with purchase receipt. Assembly of this product may require more than one person.

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 25.2 Watts (0.21 Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product, inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections and wires. If the product is placed somewhere other than the ground it should be well secured and stable.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

Guarantee

What is Covered

The product is intended for residential seasonal use for 90 days per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipts to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday



Thank you!

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 40in 105 Light LED DOG. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home decoration needs. Thank you for choosing Home Accents!


1-877-527-0313

HOMEACCENTSHOLIDAY.COM

Parts List		
Locater	Name	Qty.
A	Antler	2
B	Head	1
C	Ear	2
D	Halves of Body	2
E	Front Leg	2
F	Hind Leg	2
G	Tail	1
H	Scarf	1

Hardware List		
Locater	Name	Qty.
I	Ground Stake	4
J	Plastic Tie	10
K	Spare Fuse	2
L	Spare Bulb	3

Diagram of Parts




Hardware



ASSEMBLY


1 Assembling the Body

Align two Halves of Body (D) with each other and insert the connecting rods on one half with the connecting holes on the other half then fasten together at the connecting loops with Plastic Ties (J).




2 Assembling the Legs to the Body

Insert the connecting rods on each Leg (E,F) into the connecting holes on the underside of the Body (D) and fasten together at the connecting loops with the Plastic Ties (J).




3 Assembling the Head to the Body

Insert the connecting rods on the bottom of the Head (B) into the connecting holes on the top of the Body (D) and fasten together at the connecting loops with the Plastic Ties (J).




4 Assembling the Antlers to the Head

Insert the connecting rods on both Antlers (A) into the matching holes on the top of the Head.




5 Assembling the Ears and Light String to Head

Insert the connecting rods on both Ears (C) into the connecting holes of the Head (B). Wrap the Light String around the Antlers of Dog.




6 Assembling the Tail to the Body

Insert the connecting rods on the Tail (G) into the connecting holes at the rear of the Body.



7 Assembling the Scarf

Wrap the Scarf (H) around the neck of Dog.



8 Securing the Dog to the Ground

Secure the Dog to the ground with the Ground Stakes (I) by placing the Ground Stake through each paw then over the metal frame and into the ground.

