


Recommended Maximum Weight



WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.



Assembly Instruction

Furinno Large Entertainment Center

MODEL : 15113






00:30

Approx. 30 minutes







Customer Support

NEED HELP? For replacement requests or product inquiries, please contact our Customer Service Team by emailing us at support@furinno.com. Thank you for selecting Furinno!

www.furinno.com












No	Hardware I	_ist	Qty
1	SHORT ROUND POLE		6pcs
2	SMALL ROUND LEG		6pcs
3	PVC LEG WITH PLUG		7pcs
4	MINI FIX + HOUSING 4	.A	8sets
5	C/B SCREW A	()	8pcs
6	DOWEL		16pcs
7	MAGNET SET 7.8	7B 3	2sets
8	DOOR SPRING	A P	4pcs
9	HANDLE		2pcs
10	C/B SCREW B	Diminus-	4pcs
11	SHELF SUPPORT	<u>D</u>	4pcs
12	POWER PIN	0	20pcs

No	Parts List	Qty
Α	TOP PANEL	1pc
В	CENTER PANEL	1pc
С	BOTTOM PANEL	1рс
D	LEFT SIDE PANEL	1рс
Е	CENTER LEFT SIDE PANEL	1pc
F	CENTER RIGHT SIDE PANEL	1рс
G	RIGHT SIDE PANEL	1рс
Н	SHELF PANEL	1рс
I	LEFT DOOR PANEL	1рс
J	RIGHT DOOR PANEL	1рс
K	BACK PANEL	2pcs



USEFUL HINTS BEFORE YOU START:

- 1. Read each step carefully before starting.
- 2. It is important that each step is performed in correct order to avoid difficulties.
- 3. Identify, sort and count the parts before assembly.
- 4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
- 5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
- 6. Using uncompatible hardware might cause damage to product.

