EASY ASSEMBLY AND OPERATION INSTRUCTIONS

5124733_Gravedigger

CARE AND STORAGE INSTRUCTIONS

Please follow the step by step guide and enjoy your **Gravedigger!**

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking

hazard. Keep all plastic and wire parts away from children.

- 1. Please use the transformer supplied by manufacturer. 2. Please assemble item according to instructions. Connect all wires according to matching color.
- 3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep all away from the transformer, as it heats up during operation.

Please view all instructions carefully before assembling. Save this instruction sheet for future reference.

away from heat and moisture. **TROUBLE SHOOTING:**


Ensure that the item's adapter is plugged in at the Function Control Box and in the wall.
 Ensure that the switch on the function control box is on the desired setting.

For best performance operate your item indoors. When not in use, store this product in it's original packing. Keep

- If not functioning properly, ensure that cables are connected to their corresponding cable as shown in the instruction sheet (ex: Mouth doesn't move, eyes don't light up, body doesn't move).
 Be sure nothing is blocking movement or caught in moving parts.
- Ensure that the floor or surface that the item sits on is flat and level.
- Be sure nothing is blocking the sensor.



BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT **CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-877-527-0313, 1-855-428-3921.EMAIL CUSTOMERSERVICE@SVIUS.COM.**


















OPERATION INSTRUCTIONS:

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the Torso Frame, as desired.

2. Settings

Sensor: This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.

O/OFF/Try Me: This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad (Not Included). The item will operate for one audio cycle with each Try Me activation.

 ${\sf I}$ / ${\sf ON}$: This switch mode will continuously operate the lights, sound, and animation of the item.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

CAN ICES-3(B)/NMB-3(B)

Distributed by Home Depot 2455 Paces Ferry Road Atlanta, GA 30339 1-877-527-0313

