


Installation Instructions Vanity Top

Wood Crafters[®]

Customer Service **1-800-235-7747**


How To Attach Vanity Top to Vanity

1. Make sure the base of the vanity is leveled by laying a level across the top.
2. Set the vanity top on top of the vanity base, checking the location of the p-trap and drain.
3. Remove the top and install the faucet per manufacturer's installation instructions.
4. Hand tighten the pop-up drain with a wrench. Be careful not to over-tighten the pop-up drain. Over tightening may cause cracks on the marble top.
5. Apply a thin bead of silicone compound around the vanity base and set the vanity top carefully in place. Remove any excess silicone compound with a wet rag.
6. Attach water lines to faucet and connect the p-trap and drain.



How To Attach Sidesplash/Backsplash

1. Apply a thin bead of silicone on the back of the sidesplash/backsplash. Carefully place and secure it to the wall. Remove any excess compound.
2. Once secured, seal bottom portion of the sidesplash/backsplash by applying a thin bead of silicone on it. Let rest until dry.



Care & Maintenance:

Your vanity top will remain in its original state if you maintain and clean it properly. Clean the surface with a glass cleaner or other household cleansers that do not contain chlorine. Avoid using abrasive cleaners as they will damage the surface. Should the top become stained or scratched use a 600-grit sand paper and water.

5 YEAR
WARRANTY
GARANTIA DE 5 AÑOS



Limited Lifetime Warranty

The product has been manufactured by WoodCrafters Home Products, LLC and is warranted under normal use and service, to be free from defects in material and workmanship for the life of the product from the date purchased. During this warranty period, WoodCrafters Home Products, LLC will repair or replace at WoodCrafters Home Products, LLC sole option, free of charge, any defective part or parts returned with shipping charges prepaid to the distribution center listed below. Please include the original receipt with date of purchase and the nature of the problem. Merchandise not returned prepaid will be refused. Our warranty does not cover damage or failure caused by abuse, misuse, abnormal usage, faulty installation, improper maintenance or any repair other than those by WoodCrafters Home Products, LLC. There are no obligations or liabilities on the part of WoodCrafters Home Products, LLC for consequential damage arising out of or in connection with the use or performance of the product or any indirect damages included, but not limited to labor charges for installation or removal. This warranty gives you specific legal rights, and you may also have other rights that may vary from state to state. Further information regarding this warranty may be obtained without charge by contacting WoodCrafters Home Products, LLC Customer Service. If any Parts are missing or damaged, please call WoodCrafters Home Products, LLC Customer Service at (800) 235-7747, between 8:00 AM and 5:00 PM C.S.T.

WoodCrafters Home Products, LLC

2700 Camino de Verdad, Weslaco, TX 78596-1266

Revised July 2009