



Bluetooth® HEADSET WITH AM/FM STEREO

COMPONENTS:

1. Digital Display
2. Radio Station + / Switch (12/24 hours) / Previous track (in BT connect mp3 player mode)
3. FM/AM/BT Switch
4. Radio Station - / Switch (12/24 hours) / Next track (in BT connect mp3 player mode)
5. Clock / Store / Play/ Pause
6. On/Off Power / Volume Adjusting Knob
7. AUX input jack
8. Microphone


INSTRUCTIONS FOR USE

-Requires 3 AAA batteries (included)

RADIO OPERATION:

1. Press the On/Off Power Knob (no.6).
2. Turn the knob (no.6) to adjust the volume from 0 to 15.
3. Press FM/ AM/ BT Switch(no.3) to switch to AM or FM stations or Bluetooth function.
4. Scan Stations:
 - A-Manually Turn: Press Radio Station + button (no.2) or Radio Station - button (no.4) to adjust the station.
 - B-Scan Stations: Press and hold Radio Station + button (no.2) or Radio Station - button (no.4) for 2 seconds to scan stations.
5. Store Channels: store 40 channels from P01 to P40 for both AM and FM stations. To scan stations to get a channel, press and hold the Clock button (no. 5) until it shows the number in the [] at the right of LCD, then press Radio Station + button (no. 2) or Radio Station - button (no. 4) to choose the number to store, then press the Clock button (no. 5) again to set it. Press the Clock button (no. 5) and press again to find your desired channel stored.

Batteries



BLUE TOOTH OPERATION:

1. Press the On/Off Power Knob (no.6).
2. Press the FM/AM/BT switch (no.3) to change to blue tooth mode.
3. Blue Tooth pairing: turn on the Blue Tooth, then find the blue tooth equipment named JH-8830BT on the mobile and connect. It will show "ON" on the LCD once the connection has been made. After this operation, the blue tooth will automatically connect the same mobile next time.
4. Play the music: after connecting, press the Clock button (no. 5) to play or pause the music. Turn the knob (no.6) to adjust the volume from 0 to 15. Press the Radio Station + button (no. 2) to play the previous track, and press the Radio Station - button (no. 4) to play the next track.
5. Talking: When a call comes in, press the Clock button (no. 5) to answer the call, or press and hold the Clock button (no.5) to reject it. When the call finishes, press any button to hang up. If a call comes in when listening to the radio or AUX music, it will automatically switch to Blue Tooth mode. Press the Clock button (no.5) to answer the call, then press and hold the Clock button (no.5) to hang up after call finished and return to radio or AUX music.

AUX-IN:

When a component is plugged into the 3.5mm AUX equipment port (no. 7), it shows "Aud" on the LCD. When the AUX jack is in operation, press FM/AM/BT switch (no. 3) to add AUX to the AM/FM/BT switch.

SETTING TIME:

1. Press and hold the Clock button (no. 5) until the time begins to blink on the LCD. Then press the Clock button (no. 5) again. The LCD will show 12H. Press the Radio Station + button (no. 2) or the Radio Station - button (no. 4) to switch to 12 hours or 24 hours.
2. Press and hold the Clock button (no.5) until the time begins to blink on the LCD. Then press the Radio Station + button (no. 2) to adjust the minute and press the Radio Station - button (no. 4) to adjust the hour.

Limited Manufacturer Warranty

FOT makes every effort to ensure that this product meets high quality and durability standards. FOT warrants to the original retail consumer a 1-year limited warranty from the date the product was purchased at retail and each product is free from defects in materials. Warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence or accidents, repairs or alterations, or a lack of maintenance. FOT shall in no event be liable for death, injuries to persons or property, or for incidental, special or consequential damages arising from the use of our products. To receive service under warranty, the original manufacturer part must be returned for examination by an authorized service center. Shipping and handling charges may apply. If a defect is found, FOT will either repair or replace the product at its discretion.

DO NOT RETURN TO STORE

For Customer Service:

Email: customerservice@focus-ontools.com or Call 1-800-348-5004