

## SINK WASTE DISPOSER COVER FLANGE , STOPPER AND STRAINER UNIT



INSTRUCTIONS ON INSTALLING  
AND USING YOUR NEW  
DISPOSER WASTE FLANGE ,  
STOPPER & STRAINER UNIT

PUSH THE FLANGE UNIT  
FULLY INTO THE WASTE INLET  
OF THE DISPOSER UNTIL THE  
DECORATIVE RIM OF THE  
FLANGE BOTTOM IS AGAINST  
THE DISPOSER WASTE RIM

PUSH THE STRAINER UNIT TO  
THE BOTTOM OF THE  
FLANGE


TO RETAIN WATER –  
SEE FIG. 1

TO RETAIN WATER  
PUSH THE KNOB



TO DRAIN SINK –  
SEE FIG. 2

TO EMPTY THE SINK ,  
LIFT THE KNOB



STOPPER AND STRAINER UNIT

THE STRAINER UNIT  
CAN BE REMOVED  
FROM THE FLANGE FOR  
CLEANING OR WHEN  
OPERATING THE  
DISPOSAL UNIT

