


Service Parts



Service Parts (continued)

Reference Number	Part Number	Description	Qty.
1	9445501	Housing Assembly	1
2	9445502	Trigger Assembly	1
3	9445503	O-Ring	1
4	9445504	Trigger Pin	1
5	9445505	Oil Seal	1
6	9445506	Valve Stem	1
7	9445507	Throttle Valve	1
8	9445508	Valve Spring	1
9	9445509	Exhaust Deflector	1
10	9445510	Air Inlet NPT	1
11	9445511	Washer	1
12	9445512	Ball Bearing	1
13	9445513	Front End Plate	1
14	9445514	Steel Washer	1
15	9445515	Rotor Blade	7
16	9445516	Rotor	1
17	9445517	E Clip	1
18	9445518	Cylinder	1
19	9445519	Dowel Pin	1
20	9445520	Rear End Plate	1
21	9445521	Ball Bearing	1
22	9445522	Gasket	1

Reference Number	Part Number	Description	Qty.
23	9445523	O-Ring	1
24	9445524	Switch Assembly	1
25	9445525	Steel Ball	1
26	9445526	Spring	1
27	9445527	O-Ring	1
28	9445528	End Cap	1
29	9445529	Spring Washer	4
30	9445530	Screw	4
31	9445531	Steel Washer	1
32	9445532	Hammer Dog	2
33	9445533	Hammer Pin	2
34	9445534	Hammer Cage	1
35	9445535	Anvil	1
36	9445536	Socket Retainer	1
37	9445537	O-Ring	1
38	9445538	Anvil Bushing	1
39	9445539	Gasket	1
40	9445540	Liner	1
41	9445541	Hammer Cage	1
42	9445542	O-Ring	1
43	9445543	Grease Port Screw	1