

The Showroom Series



1 855 686 0133

Niche Maintenance

To clean niche - stainless steel

Use a liquid dish detergent or cream cleaner water and soft sponge or cloth along with

Application

Apply liquid detergent or cream to surface of niche uniformly on the surface.

Rinse with water abd wipe down with dry soft sponge or cloth.

CAUTION:

Don't use any abrasives material for cleaning like steel wool or pads.

Don't use any chemicals for cleaning like waxes, alcholols, bleach, acids, solvents or harsh chemicals

The warranty will be void in case of use of unsuitable cleaning products.