




# Equipment Sizing Guide



Use the map above to determine your region and compare to the chart below to find your application size.

## 95.5% AFUE Gas Furnace (Multi-Positional) Selection

Square Footage	Region 1	Region 2	Region 3	Region 4	Region 5	Furnace Size
740-925	800-1000	895-1110	1085-1350	1215-1520	<b>40,000 BTU</b>	
925-1390	1000-1500	1110-1675	1350-2035	1520-2280	<b>60,000 BTU</b>	
1390-1850	1500-2000	1675-2235	2035-2700	2280-3040	<b>80,000 BTU</b>	
1850-2310	2000-2500	2235-2790	2700-3390	3040-3800	<b>100,000 BTU</b>	
2310-2775	2500-3000	2790-3350	3390-4070	3800-4560	<b>120,000 BTU</b>	

**Residential Sizing:** The table and charts are intended to be used as a guideline for Residential applications only. The information is based on conventional window space (<15%), insulation and building construction (8 ft. ceiling height). When including a finished basement, use 1/2 of the finished basement square footage with the rest of the area being calculated.

**Mobile/Manufactured Home Sizing:** Refer to the Date Plate located in the electrical box or kitchen cabinets. For further assistance, call Hamilton's customer service department (800) 879-0123.