



2 SETS:



COMPONENTS INCLUDED IN THE PACKAGE



THE LAMPS ARE UL LISTED.

ASSEMBLY INSTRUCTIONS:

1. Insert the harp into the saddle and lower the two harp caps until they cover the two-pronged saddle.
2. Place the shade over the assembled harp.
3. Attach the finial and tighten to secure the shade.
4. Insert the provided LED type A light bulb into the socket. This product is only suitable for connection to a 120V 60Hz supply. For indoor use only.

MAXIMUM WATT CAPACITY

The lamp socket can take up to 100-watt type A light bulb maximum capacity. Each lamp comes with an energy saving replaceable compatible LED light bulb (9W LED= 60 watt equivalent)

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it-contact a professional electrician.

	E26	9W	ETL LISTED
---	-----	----	------------

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

TO CLEAN: PLEASE USE A NON-ABRASIVE DRY CLOTH LIKE MICRO-FIBER IN CLEANING. USE MILD DISH SOAP ON DAMP NON-ABRASIVE CLOTH IF THE LAMP IS DUSTY. DO NOT USE HOUSEHOLD CLEANERS.