


Upson Pull-Down Kitchen Faucet

MODEL	SKU #	FINISH
HD67857-0001	305764886	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Spray head and Hose	RP3840401		
2	O-ring	RP60006		
3	Wearable Ring	RP64092		
4	Cartridge & Screw	RP20094		
4.1	Cartridge	RP20044	301158214	
5	Bonnet nut	RP70533		
6	Cap	RP8002801		
7	Handle assembly	RP1363201		
8	Escutcheon	RP8066701		
9	Gasket	RP80675		
10	Block	RP70421		
11	O-ring	RP60002		

Part	Description	Part #	Internet SKU #	Store SKU #
12	Quick connect assembly	RP70663		
13	O-ring	RP60089		
14	Weight clip	RP70609		
15	Weight	RP70525		
16	FastMount™	RP56096		
17	Pump kit	RP46022		
18	Flange kit	RP4604101		
19	Soap bottle	RP46024		
20	Soap dispenser kit	RP4608201		
21	Sensor control box	RP70655		
22	Battery pack	RP70514		