## **CARE AND MAINTENANCE**

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

## **NOTICE**

Please make sure that you have all parts indicated before you begin assembly of this item.



MODEL# PAT6751

Product Dimension: 16.54"W x 18.5"D x 30.3"H


Weight capacity: 300 lbs

Warning: Do not stand on the chair Warning: Do not torque bolts / screws











## **CARE AND MAINTENANCE**

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

## **NOTICE**

Please make sure that you have all parts indicated before you begin assembly of this item.



MODEL# PAT6751

Product Dimension: 23.62"W x 25.79"D x 28.74"H


Weight capacity: 40 lbs.


Warning: Do not stand on the table Warning: Do not torque bolts / screws














Lock the leg to the top by turn on the bolt to the hole as shown on the picture.