



ASSEMBLY INSTRUCTION
INSTRUCTIONS D'ASSEMBLAGE
INTRUCCIONES DE ENSAMBLAJE


U180004/0911
(PTS-11007710-100711)

Model Number(s):
N° du modèle:
Número(s) de modelo:

KW302415-XXX



ATTENTION
ATTENTION
ATENCIÓN



When installing the KW302415 wall cabinet between two 12-inch deep wall cabinets, the space between the adjacent cabinets is 29-1/2". Use fillers between the cabinets if a wider opening is required for appliance installation. Refer to appliance manufacturer's instructions for opening required.

Lors de l'installation de l'armoire murale KW302415 entre deux armoires murales de 30,48 cm de profondeur, l'espace entre les armoires adjacentes est de 74,93 cm. Utilisez des pièces intercalaires entre les armoires si une ouverture plus large est requise pour l'installation d'électroménagers. Veuillez vous référer aux directives du fabricant de l'électroménager pour connaître l'ouverture requise.

Cuando instales el gabinete de pared KW302415 entre dos gabinetes de pared de 30,48 cm de profundidad, el espacio entre los gabinetes adyacentes es de 74,93 cm. Usa separadores entre los gabinetes si se necesita una abertura más ancha para instalar electrodomésticos. Consulta las instrucciones del fabricante del electrodoméstico para la abertura requerida.