


USE AND CARE GUIDE

GLASS BISTRO TABLE



Questions, problems, missing parts?

Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!

Table of Contents

Table of Contents	
Important Safety Instructions	2
Save These Instructions	
Read All Instructions Before Use	2
Warranty	
What is Covered	
What is Not Covered	

Pre-Assembly	3
Planning Assembly	3
Hardware Included	
Package Contents	4
Assembly	5
Care and Cleaning	

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This bistro table was made for the explicit purpose of providing outdoor functions and is not to be used as a toy.

This product is intended for normal outdoor use. However, the manufacturer recommends storing and / or covering this product when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
- Use this product only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Please keep children out of the assembly area before assembly.



WARNING: Do not place heavy objects on the table.



WARNING: Weight limit for table top is 50 lbs. (22.68kg).



CAUTION: Do not locate the product near any heat source.



CAUTION: When not in use, secure the product in a cool and covered location.

Warranty

1 YEAR FRAME WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-877-527-0313 or visit HOMEDEPOT.COM.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.




NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x25 combination hex bolt	8+1
BB	ST5x12 screw	4+1
CC	M6 bolt cover	8+1
DD	Wrench	1

Pre-Assembly (continued)

PACKAGE CONTENTS




Part	Description	Quantity
Α	Table top	1
В	Table leg	4
С	Leg connector	1

Assembly

1 Attaching the table legs to the table top


- Place the table top (A) upside down on a soft surface.
- □ Slide the four table legs (B) into the table top (A).



Assembly (continued)

2 Attaching the leg connector

- □ Attach the leg connector (C) to the table legs (B) using M6x25 combination hex bolts (AA).
- □ Use the wrench (DD) to loosely tighten the M6x25 combination hex bolts (AA).
- □ Secure the table top (A) and the table legs (B) by using ST5x12 screws (BB).
- Once all of the bolts and screws are in place, fully tighten all bolts and place on M6 bolt covers (CC).



Assembly (continued)

3 Checking the table

- Turn the table right side up.
- Ensure that all connections are secure before use.



Care and Cleaning

- □ For best results, clean the frame with a damp cloth and dry throughly. This will help prevent mildew by removing dirt particle s that may accumulate.
- □ Do not clean with abrasive materials, bleach, or solvents.
- □ Store the table in a dry, sheltered place when not in use.
- □ Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

StyleWell.

Questions, problems, missing parts? Before returning to the store, call StyleWell Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.

For certification use only

Factory table ID # FTS00899J