


Use and Care Guide Mounting Clip

TOOLS REQUIRED



Phillips Screwdriver

HARDWARE INCLUDED



AA - Mounting Clip x12






BB - Mounting Screw x24

Installation

1 Install the mounting clip as follows

- Fix the mounting clips (AA) using the screws (BB) on wooden surfaces or other proper surfaces according to your design, and then clip the rope light firmly into the clips (AA).



Safety Information



WARNING: Do not mount or secure the rope light in a manner that can cut the outer jacket or damage the cord insulation. Inspect the rope light carefully before use and discard any rope lights that have a broken outer jacket, loose connections, or frayed wire insulation.



WARNING: When using this product outdoors, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury.



WARNING: Do not cover rope lighting as the covering may cause the flexible light to overheat and either melt or ignite.



WARNING: Do not puncture, cut, shorten, or splice the flexible lighting.



WARNING: Do not use if there is any damage to the light or cord insulation. Inspect periodically.



WARNING: Do not submerge the flexible light in liquids or use the product in the vicinity of standing water or liquids.



WARNING: Secure the rope lights using only the mounting clips provided. Do not secure this product with staples, nails, or similar objects that may damage insulation.



CAUTION: All units must be unplugged before you add additional segments. Only use segments recommended by the manufacturer of this lighting system.



CAUTION: Ensure all connections and the end cap on the last segment are tightly secured to prevent the entry of water.

Warranty


The manufacturer guarantees this product to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 1-877-527-0313 for repair or replacement parts or return the product to the store from which it was purchased. This guarantee does not include normal wear and tear.

Contact the Customer Service Team at 1-877-527-0313 or visit www.HomeDepot.com.

Guía de uso y cuidado

Presilla de montaje

HERRAMIENTAS REQUERIDAS



Destornillador Phillips

HERRAJE INCLUIDO






AA - 12 presillas de montaje

BB - 24 tornillos de montaje

Instalación

1 Instalar la presilla de montaje como se muestra a continuación

- Fije las presillas de montaje (AA) con los tornillos (BB) en superficies de madera u otras superficies adecuadas de acuerdo con su diseño, y luego sujete la cuerda de luces firmemente con las presillas (AA).



Información de seguridad



ADVERTENCIA: No monte o fije la cuerda de luces de una forma que pueda producir cortes en el revestimiento exterior o dañar el aislamiento del cable. Inspeccione con cuidado la cuerda de luces antes de usarla y deseche las que tengan el revestimiento exterior roto, conexiones sueltas o desgaste del aislamiento del cable.



ADVERTENCIA: Cuando utilice este producto en exteriores, siempre se deben seguir las precauciones básicas de seguridad para reducir el riesgo de incendio, descarga eléctrica y lesiones personales.



ADVERTENCIA: No cubra esta cuerda de luces ya que de hacerlo podría causar que la cuerda flexible de luces se sobrecaliente y se derrita o comience a arder.



ADVERTENCIA: No perforo, corte, recorte o empalme la cuerda flexible de luces.



ADVERTENCIA: No la use si hay algún daño en las luces o en el aislamiento del cable. Revisar periódicamente.



ADVERTENCIA: No sumerja la cuerda flexible de luces en líquidos, ni use el producto cerca de agua estancada u otros líquidos.



ADVERTENCIA: Fije la cuerda de luces usando solo las presillas de montaje que se incluyen. No fije este producto con grapas, clavos, u objetos similares que podrían dañar el aislamiento.



PRECAUCIÓN: Todas las unidades tiene que estar desconectadas antes de agregar segmentos adicionales. Use solo los segmentos recomendados por el fabricante de este sistema de iluminación.



PRECAUCIÓN: Asegúrese de que todas las conexiones y la tapa del último segmento estén bien apretadas para evitar que entre agua.

Garantía

El fabricante garantiza que este producto estará libre de defectos en materiales y mano de obra por 1 año a partir de la fecha de compra. Si este producto está defectuoso, llame al 1-877-527-0313 para repararlo o conseguir piezas de repuesto o devuelva el producto a la tienda donde lo compró. Esta garantía no incluye el desgaste normal.

Comuníquese con el equipo de Atención al Cliente al 1-877-527-0313 o visite www.HomeDepot.com.