


**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

17 PARTS LIST

DRAWING NUMBER	DESCRIPTION	PART NUMBER
1	TOP GRILL	08-5404
2	CARRYING HANDLE	08-5697
3	TOP PLATE	08-5123
4	BURNER ASS'Y	08-0123
5	WICK COVER	08-9622
6	REAR GRILL	08-5405
7	CABINET BASE	08-5323
8	WIND COVER	08-9624
9	WICK ADJUSTER ASS'Y (COMPLETE)	08-1023
10	WICK	See Specs Below
11	WICK ADJUSTER GASKET	08-4624
12	SAFETY SHUT OFF DEVICE	See 9
13	DRIP TRAY ASS'Y	08-5214
14	FUEL CAP GASKET	REF
15	FUEL CAP ASS'Y	08-4230
16	WICK ADJUSTER KNOB	08-1724
17	BATTERY CASE ASS'Y	08-2114
18	FRONT GRILL	08-5406
19	CABINET	08-5004
20	MICA WINDOW	604B
21	DOOR	08-5704
22	FUEL GAUGE	08-4897
23	FUEL GAUGE GASKET	REF
24	TANK ASS'Y	08-4014
25	IGNITER ASS'Y	08-2027
26	WICK SLEEVE	08-1223

18 EXPLODED PARTS DRAWING

NOTE : SPECIFY MODEL NUMBER AND
PART NUMBER WHEN ORDERING PARTS.



17 LA LISTA DE LAS PARTES

NUMERO EN EL DIBUJO	DESCRIPCION	NUMERO DE PARTE
1	VERJADELACIMA	08-5404
2	ASAPARALLEVAR	08-5697
3	PLATO de la CIMA	08-5123
4	QUEMADOR [MONTAJE]	08-0123
5	TAPAdela MECHA	08-9622
6	VERJATRASERA	08-5405
7	BASE del GABINETE	08-5323
8	TAPACONTRAVIENTO	08-9624
9	AJUSTADOR de MECHA [MONTAJE] (COMPLETO)	08-1023
10	MECHA	See Specs Below
11	JUNTURAdela AJUSTADOR de MECHA	08-4624
12	MECANISMO de INTERRUPTOR de SEGURIDAD	See 9
13	BANDEJAdela GOTERAS (montaje)	08-5214
14	JUNTURAdela TAPA de COMBUSTIBLE	REF
15	TAPAdela COMBUSTIBLE (montaje)	08-4230
16	BULTO del AJUSTADOR de MECHA	08-1724
17	CAJAdela PILAS (montaje)	08-2114
18	VERJADELANTERA	08-5406
19	GABINETE	08-5004
20	VENTANAdela MICA	604B
21	PUERTA	08-5704
22	MEDIDAdela COMBUSTIBLE	08-4897
23	JUNTURAdela MEDIDAdela COMBUSTIBLE	REF
24	TANQUE [montaje]	08-4014
25	IGNICIÓN [montaje]	08-2027
26	FUNDA DE LA MECHA	08-1223

18 DIBUJO EXPANDIDO DE LAS PARTES

NOTA: ESPECIFIQUE EL NUMERO DEL MODELO Y EL NUMERO DE LA PARTE AL PEDIR PARTES.

