


USE AND CARE GUIDE

Emberjack Deep Firebowl



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this fire pit. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Maintenance	
 □ To extend the life of your fire pit, clean it after each use. □ To protect fire pit finish, use a soft cloth in lieu of bare ha □ Clean the fire bowl after each use once ashes have coole □ Store assembled in a cool, dry location away from children 	ed.
Care and Cleaning	
 Do not attempt to clean the fire pit until the fire is comple Use a soft cloth to wipe the fire pit and poker. Do not attempt to clean while hot. Keep the fire pit covered when cooled and not in use. 	ely out and cooled completely.

2

Warranty

1 YEAR LIMITED WARRANTY

WHAT IS COVERED

We warrant the metal frame to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charge to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.com.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON HAMPTONBAY.COM

Retain this manual for future use.