




Replacement Parts List

Edgewood WaterSense 1-Handle Tub and Shower Faucet in Chrome

MODEL	SKU #	FINISH
HD873X-4101	304367265	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Shower flange	RP3804601		
2	Shower arm	RP3801901	204511126	663433
3	Shower head	RP3836601		
4	O-ring	RP60101		
5	Cartridge	RP20075	202666286	270530
6	O-ring	RP60091		
7	Bonnet	RP70437		
8	Sleeve	RP8029701		
9	Inverter	RP64043		

Part	Description	Part #	Internet SKU #	Store SKU #
10	Screw	RP50070		
11	Escutcheon	RP8035401		
12	Escutcheon screw	RP5006601	202251603	331780
13	Handle assembly	RP1351401		
14	Plug	RP70365		
15	Spout	RP3303201		
16	Bracket	RP7023801		
17	Hose	RP3805901		