

Operation

1 Using the Replacement Cushion

- Remove either the old cushions.
- Place either the replacement cushions onto your patio furniture.

Safety Information



WARNING: Do not locate product near any open flame.

Care and Cleaning

Cushions may be cleaned by hand with mild soap and water. Please do not use abrasive materials or cleaners such as bleach on the fabrics. Rinse the cushions thoroughly and allow drip-drying. DO NOT machine wash or tumble dry cushions as they may shrink.

In order to prolong the life of your patio furniture and accessories (such as cushions and pillows), when not in use or during any inclement weather: hail, sleet, snow, strong wind, fire, extreme heat, and freezing conditions, the patio furniture and accessories needs to be stored in a dry, sheltered place.

Warranty

2 YEAR WARRANTY

WHAT IS COVERED

We warrant the fabric to be free of manufacturing defects to the original purchaser for **two** years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product contact the Customer Service Team 7 a.m.- 7 p.m. EST Monday through Friday and 9 a.m.- 5 p.m. Saturday and Sunday at 1-800-986-3460 or visit www.HomeDecorators.com