


Adjustable Wire Hanger Installation Manual




1. This package contains 2 parts of adjustable wire hanger.



2. Locate part A and B.



3. Insert part A wire end into part B retractable insert opening.



4. Press part B retractable point down to let out part A wire and adjust wire hanger length.



5. Attach part B hanger clips to the light fixture.



6. Use carabiner hook to hang onto pole/beam.