# Assembly Instruction Sheet Item No. 647-2X

# Night Owl Night Stand with USB Port




#### Parts List

Parts List		
Part	Description	
Α	Top Set	1 Pc.
В	Bottom Shelf	1 Pc.
С	Leg	4 Pcs.


### Hardware

Part	Description	
RF10002	Small Screw	5 Pcs.
RF10146	Big Screw	4 Pcs.
RF40193	Spring Washer	4 Pcs.
RF40052	Washer	4 Pcs.
RF40008	Knob	1 Pc.
RF40103	Allen Key	1 Pc.




## **USB Adapter Specifications**


out it days of the contractions				
Input Voltage	AC 100-240V 50/60Hz			
Input Current	≤ 350mA @ 220V AC w/ full load			
Output Voltage	$5.0V \pm 0.25V$			
Load Regulation	-0.5% (Max)			
Output Current	3.1A Max			
Output Ripple	< 400mV p-p			
Efficiency	> 75% @ 220V AC			
Output Plug	USB Type A x 4			
Over Power	≈ 17W @ 220V AC			
Short Protection	Auto Recovery			




Step 1: Attach 2 Legs (C) into the Table Top (A) using 2 Screw (RF10146), 2 Spring Washer (RF40193) and 2 Washer (RF40052) as per Diag.1.



Step 3: Repeat step 2. as per Diag.3.



Step 2: Insert Bottom Shelf (B) into the grooves on Legs (C) and attach one Leg (C) using Screw (RF10146), Spring Washer (RF40193) and 2 Washer (RF40052). Then fit the Legs by screw (RF10002) as per Diag.2.



Step 4: Stand the unit upright and attach Knob (RF40008) into the Drawer Front. as per Diag.4.

Step 5.
Attach supplied AC cable from underneath the table and plug into a standard wall outlet.
Unit is now ready to accept the supplied 3-in-1 cable.

\*After multiple devices are charged simultaneously, please disconnect them in the reverse order.

