## Cycle guide

The cycle guide below shows the options and recommended fabric types for each cycle.

			● = Available option								option
CYCLE	FABRIC TYPE	DISPLAY TIME(MIN)	BASIC OPTION (*=DEFAULT)			ADDITIONAL OPTIONS					
			WASH TEMP.	SPIN SPEED	SOIL LEVEL	STEAM	COLD WASH™	DELAY WASH	EXTRA RINSE	PRE WASH	TURBO WASH™
ALLERGIENE™	Cotton, underwear, pillow covers, bed sheets, baby wear	88 ~ 132	-	EXTRA HIGH HIGH★ MEDIUM LOW NO SPIN	-	•		•	•		•
SANITARY	Heavily soiled underwear, work clothes, diapers, etc.	81 ~ 112	EXTRA HOT★	EXTRA HIGH HIGH* MEDIUM LOW NO SPIN	HEAVY NORMAL★ LIGHT	•		•	•	•	•
BRIGHT WHITES™	White Fabrics	52 ~ 79	HOT* WARM COLD TAP COLD	EXTRA HIGH HIGH★ MEDIUM LOW NO SPIN	HEAVY NORMAL★ LIGHT	•		•	•	•	•
BULKY/ LARGE	Large items such as blankets and comforters	45 ~ 68	HOT WARM★ COLD TAP COLD	MEDIUM★ LOW NO SPIN	HEAVY NORMAL★ LIGHT	•	•	•	•	•	•
HEAVY DUTY	Heavy soiled Cotton Fabrics	60 - 117	HOT WARM★ COLD TAP COLD	EXTRA HIGH* HIGH MEDIUM LOW NO SPIN	HEAVY★ NORMAL LIGHT	•	•	•	•	•	•
COTTON/ NORMAL	Cotton, linen, towels, shirts, sheets, jeans, mixed loads	27 - 99	EXTRA HOT HOT WARM* COLD TAP COLD	EXTRA HIGH HIGH* MEDIUM LOW	HEAVY NORMAL★ LIGHT	•	•	•	•	•	•
JUMBO WASH	Comforter	45 ~ 68	HOT WARM★ COLD TAP COLD	HIGH★ MEDIUM LOW NO SPIN	HEAVY NORMAL★ LIGHT	•	•	•	•	•	•
TOWELS	Towels	39 - 75	HOT WARM★ COLD TAP COLD	EXTRA HIGH* HIGH MEDIUM LOW NO SPIN	HEAVY NORMAL★ LIGHT		•	•	•	•	•
PERM. PRESS	Dress shirts/pants, wrinkle-free clothing, poly/ cotton blend clothing, tablecloths	29 ~ 56	HOT WARM★ COLD TAP COLD	HIGH MEDIUM★ LOW	HEAVY NORMAL★ LIGHT		•	•	•	•	•
HAND WASH/ WOOL	ltems labeled "hand-washable"	44 ~ 55	WARM★ COLD TAP COLD	LOW★ NO SPIN	NORMAL★ LIGHT		•	•			
DELICATES	Dress shirts/ blouses, nylons, sheer or lacy garments	30 ~ 53	WARM COLD* TAP COLD	MEDIUM★ LOW NO SPIN	HEAVY NORMAL★ LIGHT		•	•	•	•	
SPEED WASH	Lightly soiled clothing and small loads	7 ~ 25	HOT* WARM COLD TAP COLD	EXTRA HIGH* HIGH MEDIUM LOW NO SPIN	HEAVY NORMAL LIGHT★		•	•	•		•
SMALL LOAD	Normally soiled and small loads.	45	WARM★	HIGH★	NORMAL★			•			
TUB CLEAN	This cycle is designed to remove a mildewy or musty smell.	89				•		•			

Cycle time depends on type and amount of load and detergent, water pressure and chosen additional options. - If the TURBOWASH  $^{\text{TM}}$  option is on, you cannot select "No Spin" as your SPIN SPEED.

<sup>(</sup>If the TURBOWASH™ option is off, you can select "No Spin" as your SPIN SPEED.)