


NO.	PART NAME
1	Screw
2	Screw
3	Handle
4	Cover
5	O-ring
6	Trim cap
7	Cartridge lock nut
8	Cartridge adapter
9	Cartridge
10	O-ring
11	Core
12	Screw
13	O-ring
14	Index
15	Screw
16	Body
17	Washer
18	Aerator core
19	Aerator collar
20	Copper tube(hot water)
21	Copper tube(cold water)
22	O-ring
23	Rubber washer
24	Clamp
25	Screw
26	Lock nut
27	Allen key




SINGLE LEVER LAVATORY FAUCET




ASME A112.18.1/CSA B125.1

### RECOMMENDED TOOLS




Basin wrench



Channel Locks




Goggles



Adjustable Wrench



Teflon tape



Allen key

**WARNING:**  
Please keep the tool for future use!



**Attention:**  
for easy installation, you will need:  
1. To read all the installation instruction completely before beginning.  
2. To read all the warning, attention and maintenance information.  
3. To purchase the proper supply lines.

The tools might be applied to the following places:

