

Expanding Foam Sealant

1. This product is **FLAMMABLE DURING DISPENSING**. Shut off all gas pilot lights, electrical igniters and other sources of ignition before and during use. **DO NOT** smoke or use matches or lighters while dispensing foam.
2. Wear gloves and eye protection. Ensure good ventilation.
3. Protect area with cloth or newspaper.
4. Shake can vigorously for at least one minute before use.
5. Screw straw assembly onto valve.
6. Holding can **UPSIDE DOWN**, slowly pull trigger until foam flows smoothly. Never active valve with can right side up, propellant will escape. Practice on a piece of newspaper.
7. Clean up: solid surfaces, uncured foam dissolves with acetone. For skin and solid surfaces, cured foam must be mechanically removed or allowed to wear off in time.