

Multiflex LED Work Light Use & Care Instructions

Fulcrum Products, Inc.
PO Box 69035, Portland, OR 97239
info@fulcrumproducts.com

Please carefully review this instruction sheet as it contains important safety information!

Eye Safety

Do not look directly into the LED's and do not shine them into the eyes of the others. As with other high intensity light sources, eye damage may occur.

High Heat

Do not place the light over or close grilling surfaces as high heat may damage the unit and create a potential fire hazard. The MultiFlex Work Light is not constructed to be heat resistant.

Moisture

Do not leave the light outside and uncovered. The MultiFlex Work Light is not constructed to be water proof. Moisture may cause corrosion in the circuitry and result in the premature failure of this product.

Flexible arm

Do not abuse the flexible arm by extreme or severe bending as the wires inside may break, rendering the product inoperable or causing the batteries to heat up, leak, or explode.

LEDS

Do not attempt to remove or replace the LEDs. LEDs may last up to 100,000 hours and are not replaceable.

Inserting Batteries/Operation

Slide off the battery door located on the top of the clamp. Insert 3 AA size batteries in the direction indicated by the diagram located in the battery compartment.

Check the installation by pressing the on/off switch located on the tip of the lamp head. If it fails to light, then check the batteries to ensure that they have been inserted correctly.

Battery Safety

Improper use of this or any battery-operated product may cause batteries to leak or explode, which may cause personal injury. Battery leaks can cause chemical burns. To avoid unnecessary exposure to these hazards, we recommend the following precautions:

- Alkaline batteries are recommended.
- Remove batteries when the light is not in use for an extended period.
- Replace batteries when light output becomes weak or nonexistent.
- Do not mix old and new batteries
- Do not mix alkaline, carbon-zinc, or rechargeable (nickel-cadmium) batteries.
- Do not attempt to recharge non-rechargeable batteries
- Keep the battery compartment free of any metallic (or other) debris
- In the event of injury, flush the area with cold water and contact a physician

Warranty

The MultiFlex Work Light is guaranteed against manufacturing defects for a period of one year. Please contact your local retailer or place of purchase for details.

