


24 Gauge Galvanized Base with Adjustable Elastomer Collar • 1 ¼ - 1 ½ inch, 2 inch & 3 inch Do not use petroleum based mastics, sealing compounds or paint on elastomer collar




Using the pull tabs, adjust the size of the opening to fit the pipe.



1. After shingling up to the pipe, slide flashing down over pipe.



3. Secure flange with 6 roofing nails.



4. Continue shingling above the vent pipe to complete the installation. The tight neoprene seal means there's no need for any sealant at the base of the pipe.



CAUTION!

Working above grade is inherently dangerous, be sure that proper fall protection measures are in place. When working with power tools and sheet metal, gloves and eye protection are absolutely required.

These basic installation guidelines are for use with typical or standard applications. It is always recommended to seek advice from a licensed professional, and to check with your local building inspector or building permit office for approvals and possible variations that may apply.