




USE AND CARE GUIDE

MARIN 18.5" 3 LIGHT PENDANT



Questions, problems, missing parts? Before returning to the store, Please contact Fifth and Main Customer Service at fifthandmainsupport@troycsl.com

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	
What is Covered	
What is Not Covered	2
Pre-installation	3
Planning Installation	

Installation (continued)		
Installation	5	
Package Contents	4	
Pre-installation (continued)	4	
Hardware Included	3	
Tools required	3	

Safety Information

- Read all instructions before assembling and installing the product.
- Consult a qualified electrician for installation of this fixture.
- If you have any non-electrical questions about this, please contact the customer service fifthandmainsupport@troycsl.com
- □ Save these instructions for future reference.



WARNING:

Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

CAUTION:



Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation. Please contact our customer service department fifthandmainsupport@troycsl.com

Warranty

WHAT IS COVERED

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of three (3) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If his product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect, or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship.

WHAT IS NOT COVERED

This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor / expense costs involved in the replacement or repair of said product.

Contact the Customer Service <u>fifthandmainsupport@troycsl.com</u>

Pre-installation


PLANNING INSTALLATION

- □ Read all instructions before installation
- □ To avoid damaging this product, assemble it on a soft, non- abrasive surface, such as carpet or cardboard.



NOTE: Keep your receipt and these instructions for proof of purchase.


TOOLS REQUIRED



HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.











CC




DD

Part	Description	Quantity
AA	Crossbar	1
BB	Outlet box screw	2
CC	Wire nut	3
DD	Ground screw	1

Pre-installation- (continued)

PACKAGE CONTENTS




Part	Description	Quantity
А	Canopy	1
В	Canopy loop	1
С	Canopy Loop ring	1
D	Loop	1
E	Fixture frame	1
F	Metal hoop	1
G	Crystal bobeche	3
Н	bulb	3 (not included)

Installation


1 Align fixture frame

 Pull open the Fixture frame(E) according to the arrows as below.

Before:




After:




2 Insert metal hoop

□ Insert the metal hoop(F) into the Fixture frame (E) as shown. Slide end of hoop into coupler as shown.




3 Installing the lighting fixture

□ Screw the Loop (D) into the Fixture frame(E).



4 Attach the cross bar to the outlet box


☐ The Outlet box screw (BB) go through the Cross bar (AA) to be locked to the outlet box



Installation


5 Connecting the electrical wires

- Connect the copper wire from the fixture frame (E) to the Crossbar (AA) by securing it with the preinstalled Ground screw(DD).
- Connect the white wire from the fixture to the white wire(neutral wire) from the outlet box.
- Connect the black wire from the fixture to the black wire(live wire) from the outlet box.
- □ Cover the three connections using the three wire nuts(CC), Wrap the three wire connections with electrical tape for a more secure connection.
- Position the wire back inside the outlet box.




6 Canopy installation

 Raise the canopy(A) to Canopy loop(B) to outlet box and then secure it by fixing the canopy loop ring(C)




7 Installing the bobeche

Put the Crystal bobeche (G) on above the socket



8 Installing the bulb

- Install the bulb(not included). Be sure to use light bulb(s) with wattage no greater than specified on this fixture.
- Recommend B10 candelabra base clear bulb, 60 watts max





Questions, problems, missing parts? Before returning to the store, Please contact Fifth and Main Customer Service at fifthandmainsupport@troycsl.com

Retain this manual for future use.