


USE AND CARE GUIDE

PEMBREY 70 in. x 40 in. DINING TABLE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8:00 a.m. - 6:00 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	2
3 Year Frame	
Limited Warranty	2
What Is Covered	
What Is Not Covered	2
Care Instructions	2

Pre-Assembly	3
Planning Assembly	
Hardware Included	
Package Contents	4
Assembly	5

Safety Information



DANGER: Please keep children out of the assembly area before assembly.



WARNING: Do not sit or stand on the table.



WARNING: Do not put heavy objects on the table.



CAUTION: Use the table on flat ground only.



IMPORTANT: Please check the tightness of the bolts at least every 90 days.



NOTE: Level the table with glides at the bottom of each leg.

Warranty

3 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Care Instructions

Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. Treat the frame with liquid wax for maximum protection against UV light and salty, damp air. When not in use, store furniture in a cool, dry place. If your set includes cushions or mesh fabric, they may be cleaned by hand with a mild solution of soap and water. Rinse cushions thoroughly and allow to drip dry. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics. When cleaning the tabletop make sure to use a soft, clean cloth that does not bleed color.

You may contact our customer service department with any questions by phone at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

It will take two people about 10 minutes to complete the assembly process.

Assemble this product on a blanket or towel or other soft, non-abrasive surface to avoid scratching the finish.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.

ΔΔ
AH



(O) ____C






Part	Description	Quantity
AA	Bolt (M6 x 15 mm)	8
BB	Bolt (M6 x 25 mm)	8
CC	Metal Washer	16
DD	Plastic Bolt Cap	16
EE	Hex Wrench	1


Pre-Assembly (continued)

PACKAGE CONTENTS









Part	Description	Quantity
Α	Table Top Rim	1
В	Ceramic Tile	4
C	Leg Connector Bracket	1
D	Table Leg	4

Assembly

Attaching the legs to the table top rim


☐ With the assistance of another person, place the table top rim (A) upside down so the pre-drilled corner holes are visible.

Align and attach each of the four table legs (D) in the corners of the table top rim (A), by inserting bolts (AA) with metal washers (CC) through the pre-drilled holes.

Loosely tighten with the hex wrench (EE).



IMPORTANT: Do not tighten completely until assembly is completed.




2 Attaching the leg connector bracket to the legs

Attach the leg connector bracket (C) to each of the table legs (D) by inserting bolts (BB) with metal washers (CC) into the pre-drilled holes, using the hex wrench (EE).




IMPORTANT: Each of the leg bolts should be attached and initially tightened only a few revolutions. Then tighten further, one bolt at a time, alternating between the four legs. Do NOT fully tighten one leg before you attach the other legs.



Attaching the bolt caps and putting the ceramic tiles onto the table frame

- ☐ Tighten all the bolts using the hex wrench (EE). Cover them with the plastic bolt caps (DD).
- □ With assistance, turn the table in the upright position.

 Carefully place the ceramic tiles (B) onto the table frame.





Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8:00 a.m. - 6:00 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.