
HAMPTON BAY

USE AND CARE GUIDE

BEACON PARK RECTANGULAR DINING TABLE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	2
Important Safety Instructions	
Save These Instructions	
Read All Instructions Before Use	
Warranty	3
What is Covered	3
What is Not Covered	3

Pre-Assembly	3
Planning Assembly	
Hardware Included	
Package Contents	4
Assembly	5
Care and Cleaning	10

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This dining table was as made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this product when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
- 2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Please keep children out of the assembly area before assembly.
- 4. This table is not intended to support an umbrella. Umbrellas must have a suitable base or stand.



WARNING: This table unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not place heavy objects on the table top.

Warranty

3 YEAR LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HamptonBay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED





NOTE: Hardware not shown to actual size.












Part	Description	Quantity
AA	M6x15 combination bolt	6+1
BB	M6x30 combination bolt	8+1
CC	M6x40 combination bolt	3+1
DD	M6x55 combination bolt	1+1
EE	M6 washer	3+1
FF	M6 nut	3+1
GG	Wrench	1
HH	Hex wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Table top	1
В	Table top with umbrella hole	1
С	Table leg	2
D	Leg connector 1	1
E	Leg connector 2	1
F	Umbrella cap	1
G	Knob	1


Assembly

1 CONNECTING THE TABLE TOPS

- □ Place the table tops upside down on a soft surface.
- Attach the table top (A) to the table top with umbrella hole (B) using M6x40 combination bolts (CC), M6 washers (EE) and M6 nuts (FF).
- Do not fully tighten the bolts at this step.



NOTE: Loosely tighten all bolts using the wrench (GG) and hex wrench (HH).




2 ATTACHING THE TABLE LEGS TO THE TABLE TOP

- Attach the table legs (C) to the assembled table top using M6x30 combination bolts (BB).
- Do not fully tighten the bolts at this step.



NOTE: Loosely tighten all bolts using the hex wrench (HH).




3 ATTACHING THE LEG CONNECTORS TO THE TABLE LEG

- □ Attach the leg connector 1 & 2 (D & E) to the table legs (C) using M6x15 combination bolts (AA).
- Do not fully tighten the bolts at this step.



NOTE: Loosely tighten all bolts using the hex wrench (HH).




4

CONNECTING THE LEG CONNECTOR 1 TO THE TABLE TOP WITH UMBRELLA HOLE

- □ Connect the leg connector 1 (D) to the table top with umbrella hole (B) using an M6x55 combination bolt (DD).
- Do not fully tighten the bolts at this step.




NOTE: Loosely tighten all bolts using the hex wrench (HH).




5 CONNECTING THE LEG CONNECTORS

- □ Connect the leg connector 1 (D) to the leg connector 2 (E) using the knob (G).
- □ Place the umbrella cap (F) on the table top with umbrella hole (B).



6 CHECKING THE TABLE

- Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (HH) and the wrench (GG).
- □ Turn the table right side up.
- □ Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the table with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- $\ \square$ Do not clean with abrasive materials, bleach, or solvents.
- □ Store the table in a dry, sheltered place when not in use.
- □ Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON HAMPTONBAY.COM

Retain this manual for future use.

For certification use only

Factory table ID # FTS61192