
## **Assembly Manual**

## Saka Side Table

**P1** 



## ACCESSORY LIST



				AS	SE	MBLY I	PIECES
NO	Lenght	Widht	Thick	PCS.		NO	Lengh
01	432	300	18	1		05	182
02	432	300	18	1		06	364
03	450	300	18	1		07	200
04	400	300	12	1			

Lenght	Widht	Thick	PCS.
182	300	18	1
364	120	18	1
200	182	18	1
	182 364	182 300 364 120	364 120 18

## Dear Customer,

The product you bought was subjected to all sorts of test and control before sending out to you. Even in this situation, sometimes happen that some component is damaged durin the transportation. In such please do not sent the whole article back us. Just request/order the damaged part. While requesting the required part, describe it exactly by looking to service card. Missing part will be sent you as soon as possible. Before start assembling, please check the whole components and accessories according to the lists. After being sure that every part and accessory are okay and right, start assembling. Before start assembling, please clean all the components with a damp cloth. If you bought more than one product, to prevent confusion be sure that you completed the first product. Then start the other product's assembling.

Never drag the products. While carrying, disassociate and lift the product and carry with minimum 2 people. For long distances carry the product with the package.

It is very easy to clean the surfaces of your product. It is enough to wipe a damp and soapy cloth or other household cleaners.

Do not directly contact your furniture with excessive heat, cold and humidity because the product can be affected.

Do not use your furniture out of purposes.

