

# PRESTO®

## Stainless Steel Coffee Maker



## Instructions

This is a  Listed appliance. The following important safeguards are recommended by most portable appliance manufacturers.

### IMPORTANT SAFEGUARDS


To reduce the risk of personal injury or property damage, when using electrical appliances, basic safety precautions should always be followed, including the following.

1. Read all instructions.
2. To protect against electrical shock, do not immerse cord, plugs, or coffee maker in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Do not let cord hang over edge of table or counter, or touch hot surfaces.
5. Be sure that the lid is securely in place before brewing and serving coffee.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return the appliance to the Presto Factory Service Department or to the nearest Presto Authorized Service Station for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
8. Do not touch hot surfaces. Use handles or knobs.
9. Do not place on or near a hot gas or electric burner or in a heated oven.
10. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, remove plug from wall outlet, then from appliance.
11. Remove and replace lid carefully.
12. Scalding may occur if lid is removed during brewing cycle.
13. Extreme caution must be used when moving coffee maker containing hot liquids.
14. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
15. Do not use outdoors.
16. Do not use appliance for other than intended use.

### SAVE THESE INSTRUCTIONS

This product is for household use only.

## How to Use



**IMPORTANT:** To assure proper operation, read and follow instructions carefully. Before using for the first time, wash the inside of the coffee maker, cover and basket assembly with hot sudsy water. Rinse thoroughly. **DO NOT IMMERSE COFFEE MAKER IN WATER OR OTHER LIQUID.**

1. For perfect coffee every time, always fill your coffee maker with fresh COLD water. Fill to desired level, see fill level indicator inside the body. Make at least 2 cups at a time to assure best flavor.
2. Place either regular or percolator grind coffee in the basket. When adding coffee to basket, place a finger over the stem to prevent grounds from falling through.

**Note:** The coffee maker's rapid percolating action may cause sediment to collect on the bottom of the pot. The sediment can be reduced by using a percolator coffee filter (available from most grocers) in the perk basket.

The following suggested amounts of coffee can be adjusted according to personal preference:

| CUPS OF BREW | TABLESPOONS OF COFFEE |
|--------------|-----------------------|
| 2            | 3                     |
| 4            | 4-5                   |
| 6            | 5-6                   |
| 8            | 6-8                   |
| 10           | 8-10                  |
| 12           | 8-12                  |

3. Cover the basket with the basket lid. Slip the basket on the perk tube and seat the perk tube in the coffee maker perk well. **IF THE PERK TUBE IS NOT SEATED PROPERLY IN THE PERK WELL, THE COFFEE MAKER WILL NOT PERK.**
4. Place the cover firmly on the coffee maker.
5. Connect the cord to the coffee maker then to a standard AC wall outlet. Never plug coffee maker in without water or liquid coffee in it.

A short cord set has been provided to reduce risks resulting from becoming entangled in or tripping over a longer cord. Longer cord sets or an extension cord may be used if care is exercised in their use.

If a longer cord set or an extension cord is used, the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance. **The longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over.**

6. The signal light comes on automatically when coffee is ready.  
Coffee stays hot as long as coffee maker is plugged in.
7. Disconnect the cord from the electrical outlet first and then from the coffee maker before washing the unit.

**To make additional coffee**, rinse coffee maker with COLD water before brewing successive pots.

**To reheat**, remove the basket and perk tube from the coffee maker. Heat 3 to 5 minutes depending on the amount of coffee left in the coffee maker. Do not reheat with less than 4 cups in the coffee maker.

## Care and Cleaning

1. Unplug cord from electrical outlet and then remove from coffee maker. ALLOW the coffee maker to cool before cleaning.
2. Wash and rinse inside of coffee maker, cover and basket assembly with hot soapy water after each use. DO NOT IMMERSE THE COFFEE MAKER IN WATER OR OTHER LIQUID. The perk tube and spout can be cleaned with a brush or pipe cleaner.
3. Wipe outside surface with damp cloth. Thoroughly dry with a towel. DO NOT IMMERSE COFFEE MAKER.
4. Periodically remove oils and stains from inside the coffee maker with a coffee stain remover.

## Service Information

If you have any questions regarding the operation of your Presto® appliance or need parts for your appliance, **call our Consumer Service Department** weekdays 8:00 AM to 4:30 PM (Central Time) at 1-800-877-0441 or write:

**NATIONAL PRESTO INDUSTRIES, INC.**

**Consumer Service Department**

**3925 North Hastings Way, Eau Claire, WI 54703-3703**

You may also email your inquiries to **contact@GoPresto.com**. Inquiries will be answered promptly by telephone, letter, or email. When writing, please include a phone number and a time when you can be reached during weekdays if possible.

Any maintenance required for this product, other than normal household care and cleaning, should be performed by our Factory Service Department or any Presto Authorized Service Station. Be sure to indicate date of purchase and a description of defect when sending an appliance for repair. **Send appliances for repair to:**

**CANTON SALES AND STORAGE COMPANY**

**Presto Factory Service Department**

**555 Matthews Dr., Canton, MS 39046-0529**

Appliances may also be repaired at any Presto Authorized Service Station. Check your yellow pages for Service Stations near you.

The Presto Factory Service Department and Presto Authorized Service Stations are equipped to service all PRESTO® appliances and supply genuine PRESTO® parts. Genuine PRESTO® replacement parts are manufactured to the same exacting quality standards as PRESTO® appliances and are engineered specifically to function properly with its appliances. Presto can only guarantee the quality and performance of genuine PRESTO® parts. "Look-alikes" might not be of the same quality or function in the same manner. To ensure that you are buying genuine PRESTO® replacement parts, look for the PRESTO® trademark.

### PRESTO® Limited Warranty

This quality PRESTO® appliance is designed and built to provide many years of satisfactory performance under normal household use. Presto pledges to the original owner that should there be any defects in material or workmanship during the first two years after purchase, we will repair or replace it at our option. Our pledge does not apply to damage caused by shipping. To obtain service under the warranty, return this PRESTO® appliance, shipping prepaid, to the nearest Presto Authorized Service Station, or to the Factory Service Department. When returning a product, please include a description of the defect and indicate the date the appliance was purchased.

We want you to obtain maximum enjoyment from using this PRESTO® appliance and ask that you read and follow the instructions enclosed. Failure to follow instructions, damage caused by improper replacement parts, abuse or misuse will void this pledge. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is Presto's personal pledge to you and is being made in place of all other express warranties.

NATIONAL PRESTO INDUSTRIES, INC.  
Eau Claire, WI 54703-3703