
USE AND CARE GUIDE

1-LIGHT OUTDOOR POST MOUNT



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this 1-light outdoor post mount. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents	
Safety Information	2
Warranty	2
What is Covered	2
What is Not Covered	2
Pre-installation	3
Planning Installation	

Tools Required	3
Hardware Included	3
Package Contents	4
Installation	
Care and Cleaning	7
Troubleshooting	7

Safety Information



WARNING: Carefully read and understand the information given in this manual before beginning the assembly and installation of the product. Failure to do so could lead to electric shock, fire, or other injuries which could be hazardous or even fatal.

NOTICE:

Suitable for wet locations.

 \triangle

WARNING: Be sure the electricity to the wires you are working on is shut off. Either remove the fuse or turn off the circuit breaker.

NOTICE: The luminaires shall be installed by a qualified electrician or person who is familiar with the luminaires.

NOTICE: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

Warranty

WHAT IS COVERED

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect, or mishandling.

WHAT IS NOT COVERED

This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface discoloration and/or weathering, as this is considered normal wear and tear.

The manufacturer does not warrant and specifically disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.

Contact the Customer Service Team at 1-800-986-3460 or visit HOMEDEPOT.COM/HOMEDECORATORS.

Pre-Installation


PLANNING INSTALLATION

Read all instructions before installation. Before starting the installation of this fixture or the removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: Keep your receipt and these instructions for proof of purchase.

TOOLS REQUIRED



HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	Wire Connector	3

Pre-Installation (continued)

PACKAGE CONTENTS




Part	Description	Quantity
Α	Fixture	1
В	Metal Lamp Holder	1
С	Ball Finial (preassembled to Fixture (A) and Metal Lamp Holder (B))	4
D	Post Screws	3

Installation


Installing the fixture

- □ Remove the Ball Finials (C) from the Fixture (A) and Metal Lamp Holder (B).
- □ Remove the Post Screws (D) from the Metal Lamp Holder (B).




2 Installing the fixture

- Connect the ground wire from the Metal Lamp Holder (B) to the ground wire from the Pillar.
- □ Connect the white wire from the Metal Lamp Holder (B) to the white wire (neutral wire) from the Pillar.
- □ Connect the black wire from the Metal Lamp Holder (B) to the black wire (live wire) from the Pillar.
- □ Cover the three connections using the three Wire Connectors (AA). Wrap the three wire connections with electrical tape for a more secure connection.
- □ Position the wires back inside the Pillar.



3 Installing the fixture

□ Secure the fixture assembly to the post using the Post Screws (D).





CAUTION: DO NOT INSTALL ON POST OR ROLE THAT RESULTS IN A VERTICAL RISE OF 25 FEET OR HIGHER.


Installation (continued)

4 Installing the bulb

□ Screw the bulb (not included) into the socket.




NOTE: Use 60-watt max. medium-base bulbs or equivalent energy-saving bulbs (sold separately).



5 Securing the fixture

- $\hfill\Box$ Place the Fixture (A) on the Metal Lamp Holder (B).
- ☐ Align the holes from the Fixture (A) and Metal Lamp Holder (B).
- □ Secure with Ball Finials (C).



Care and Cleaning

- □ Clean the fixture with a soft, dry cloth.
- □ Do not use any cleaners with chemicals, solvents or harsh abrasives.



CAUTION: Before attempting to clean the fixture, disconnect the power to the fixture by turning the breaker off or removing the fuse from the fuse box.

Troubleshooting

Problem	Possible cause	Solution
The fixture will not light.	The power is off.	Ensure the power supply is On.
	The circuit breaker is off.	Ensure the circuit breaker is in the On position.
The fuse blows or the circuit breaker trips when the light is turned on.	The wires are crossed or the power wire is grounding out.	Check the wire connections. Contact a qualified electrician or call the Customer Service Team at 1-800-986-3460.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.