


USE AND CARE GUIDE

11 FT. LED OFFSET SOLAR UMBRELLA



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	2
Product Caution	2
Safety Warnings	2
Warranty	
What is Covered	2
What is Not Covered	2

Pre-Assembly	
Planning Assembly	
Hardware Included	3
Package Contents	4
Assembly	5
Operation	18
Care and Cleaning	24
Maintenance	25

Safety Information


PRODUCT CAUTION

This umbrella was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this umbrella when any formidable / severe weather is approaching. Do not locate the product near open flame. Do not use the product as a support. Do not shake, lean or climb on product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

SAFETY WARNINGS



WARNING: Please keep children out of the assembly area before assembly.





WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



CAUTION: Always close and secure the product when not in use and in the event of inclement weather.



CAUTION: Never use the umbrella in high wind conditions. Damage to the umbrella can occur.



CAUTION: Keep all flame and heat sources away from this product at all times.

Warranty

1 YEAR FRAME AND 1 YEAR FABRIC WARRANTY

WHAT IS COVERED

We warrant to be free of manufacturing defects to the original purchaser for one year frame and one year fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchase parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HamptonBay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M8x20 combination hex bolt	4+1
BB	M5x8 bolt	2+1
CC	Wrench	1
DD	Hex wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Lower bracket	1
В	Upper bracket	1
C	Lower umbrella pole	1
D	Locking knob	1
Е	Solar receiver	1
F	Crank	1
G	Umbrella shade	1
Н	Lower base cover	2

Part	Description	Quantity
I	Upper base cover	1
J	Support tube rim	2
K	Corner connector	4
L	Side panel	2
М	Lock panel	2
N	Sand bag	1


Assembly

1 Attaching the brackets

□ Attach the upper bracket (B) onto the lower bracket (A).



NOTE: This umbrella should be set up in its desired location to avoid moving it after assembly.




2 Attaching the lower umbrella pole to the brackets

Attach the lower umbrella pole (C) to the upper bracket (B) and lower bracket (A) using M8x20 combination hex bolts (AA).




NOTE: Fully tighten all bolts using the wrench (CC).



3 Inserting the corner connectors


Insert the corner connectors (K) into the four ends of the assembled brackets.



Please contact 1-855-HD-HAMPTON for further assistance.


4 Sliding the lock panels

□ Slide the perforated lock panels (M) downward between the corner connectors (K).



5 Sliding the side panels

- □ Connect the two pieces of the support tube rims (J).
- □ Slide the support tube rims (J) down the lower umbrella pole (C) and connect it to the brackets (A and B).




6 Placing the sand bags

Place the sand bags (N) in the umbrella base.



NOTE: Place the base in the area where the umbrella is to be used. The umbrella will be very heavy after filled with sand.



7 Filling the sand bags


- Pull to open the velcro pouch on the sand bag (N) and fill with sand.
- □ After filling the sand bags (N), close the pouch and ensure the velcro is sealed.
- □ Lock the two sections of the sand bags (N) together.



NOTE: The sand bags (N) are to be filled with sand only.




NOTE: For proper stability of the offset umbrella, please place 110 lbs of sand into each sand bag for a total of 220 lbs.




8 Ensuring the locking mechanism is in the open position

- Ensure the locking mechanisms on the lock panel (M) are in the OPEN position by using the wrench (CC) as shown in figure 1.
- □ Ensure the locking mechanisms on the lower base covers (H) are in the OPEN position by using the wrench (CC) as shown in figure 2.
- □ Attach the lower base covers (H) to the side panels (L).
- □ Close the lower base covers (H) and ensure they are fully closed.



9 Locking the lower base covers

- Lock the lower base covers (H) and the lock panel (M) by turning the locking mechanisms to the CLOSE position using the wrench (CC) as shown in figure 1 and figure 2.
- □ Attach the upper base cover (I) to the assembled base.




1 Attaching the locking knob to the lower umbrella pole

Attach the locking knob (D) to the lower umbrella pole (C) using the M5x8 bolts (BB) and hex wrench (DD). Make sure the locking knob (D) is placed as shown in figure 1 before attaching.




NOTE: When inserting the locking knob (D) into the hole, make sure the two points of the locking knob fit into the two slots on the umbrella pole as shown below.



11 Preparing the umbrella

Push the long bent tube of the umbrella shade (G) outwards a little while holding down the tap on the short bent tube to make the hinge slide snap into place as shown below.




Please contact 1-855-HD-HAMPTON for further assistance.

12 Attaching the solar reciever

- Attach the solar receiver (E) to the umbrella shade (G) by turning the solar receiver (E) clockwise until fully tightened.
- Insert the plug into the plug hole of the solar receiver (E).



NOTE: Please leave the solar receiver (E) out in a sunny area to charge before the first time turning on the LED lights.




13 Inserting the umbrella shade into the lower umbrella pole

- Rotate the locking knob (D) 180 degrees clockwise as shown in figure 1.
- □ Insert the umbrella shade (G) into the lower umbrella pole (C) as shown in figure 2.
- □ Rotate the locking knob (D) 180 degrees clockwise as shown in figure 3.



NOTE: If there is a gap in the locking knob (D) as shown below in figure 3, please rotate the umbrella shade (G) until it is completely locked as shown in figure 4.




Operation

Attaching and detaching the crank

- □ Attach the crank (F) to the handle as shown in figure 1.
- Attach the crank (F) by aligning the tap with the hole on the crank (F) until it snaps into place.
- □ To detach the crank, the hex wrench (DD) is required to press the tap to take the crank (F) out.
- □ Attach the crank (F) without using the tap as shown in figure 2.
- □ To detach the crank (F), just take the crank out.




NOTE: Both methods of attaching the crank (F) are acceptable.




? Raising the umbrella

- □ Loosen the knob on the umbrella shade as shown in figure 1 by turning it counterclockwise until it is fully loose.
- □ Hold the umbrella handle and push the long bent tube upward as shown in figure 2 until it stops and the umbrella is fully extended.
- □ Fully tighten the knob on the umbrella shade clockwise as shown in figure 3 to lock the handle in place.




3 Opening the umbrella

- □ Undo the velcro belt on the canopy and shake the canopy to separate the umbrella ribs.
- □ Slowly turn the crank (F) clockwise to open the umbrella.
- When the umbrella is fully open, fasten the belt under the hinge of the short bent tube to stabilize the umbrella. Make sure the belt is tightened as shown in figure 3.



4 Operating the umbrella


- Rotate the locking knob (D) 180 degrees clockwise as shown in figure 1.
- □ Hold the umbrella handle with one hand and hold the short bent tube with the other hand to rotate the umbrella as shown in figure 2. (The umbrella can rotate up to 360 degrees.)
- □ When the umbrella is at the desired position, rotate the knob 180 degrees clockwise as shown in figure 3.
- □ Rotate the umbrella shade (G) untill the locking knob (D) automatically secures as shown in figure 4.



21


5 Operating the umbrella

- □ Press the ON/OFF switch to turn the LED light on and off.
- Fully loosen the knob on the umbrella shade (G) by turning it counterclockwise, then slide the umbrella handle down to adjust the angle of the umbrella.
- □ When the umbrella is at the desired angle to shade the sunlight, fully tighten the knob by turning it clockwise.




6 Closing the umbrella

- Loosen the velcro belt as shown in figure 1.
- \Box Turn the crank counterclockwise to close the umbrella as shown in figure 2.
- □ When the umbrella is closed, fully loosen the knob by turning it counterclockwise as shown in figure 3
- Hold the handle and pull the long bent tube downward as shown in figure 4.
- ☐ Tighten the knob by turning it clockwise as shown in figure 5 after closing the umbrella.



NOTE: To adjust the umbrella shade to the original position before closing, follow these steps:


- Fully loosen the knob on the umbrella shade by turning it counterclockwise.
- Slide the handle on the long bent tube upwards.
- When the long bent tube is pushed to the top, fully tighten the knob by turning it clockwise.



Maintenance (continued)

7 Storing the umbrella

Tie the umbrella to the umbrella pole with the velcro belt when not in use as shown below.




Care and Cleaning

- For best results, clean the frame and fabric with a damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach, or solvents.
- □ Store the umbrella in a dry, sheltered place when not in use.
- Tie the canopy closed on windy days to prevent damage to the umbrella.
- Keep the umbrella away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Maintenance

1 Removing the light bar


- □ Remove the umbrella cover from the umbrella rib, as shown in figure 1.
- ☐ Gently pull out the wire from the umbrella rib until the plug connection appears, then disconnect the plug, as shown in figure 2.
- □ Pull out the light bar, as shown in figure 3.



Maintenance (continued)

2 Installing the replacement light bar

- □ Insert the light bar into the umbrella rib, as shown in figure 1.
- Connect the plug from the umbrella rib to the plug of the replacement light bar, and insert the extra wire into umbrella rib, as shown in figure 2.
- □ Place the umbrella cover to the umbrella rib, as shown in figure 3.





Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM