## Insert

## INSTRUCTIONS:

 Locate the segments around the outer edge of the timer's dial. These segments, each representing 30 minutes, can be pushed down from the edge of the dial (try using the tip of a pen or pencil). Conversely, segments that have been pushed down can be easily pulled back up by hand. Be sure all segments are pulled up before programming. Select a time period (or periods) you want the lamp turned on, then push down ALL the segments that fall on or within that

Select a time period (or periods) you want the lamp turned on, then push down ALL the segments that fall on or within that time period. For example, to have the timer turn a lamp on at 10PM and off at 2AM, push down the segments representing 10PM and 2AM, and ALL the segments in between (See **Figure 1**). You may need to turn the dial clockwise to access the desired segments.

- 2. Rotate the timer's dial clockwise until the pointer on the face of the dial points to the current time of day. Note: Nighttime hours (from 6:30PM to 6:30AM) are highlighted with a grey background.
- 3. Set master switch to the TIMER ON position. (See Figure 2)
- 4. Plug the timer into an electrical outlet convenient to the lamp to be controlled.
- 5. Plug the lamp into either outlet on the sides of the timer. Turn the lamp's switch on for automatic control. The timer will not turn the lamp on if the lamp's switch is off. The lamp will now turn on and off at the times you have set. The setting on the timer will be used for both outlets simultaneous.

**NOTE:** To override the timer and use your lamp normally, set the master switch to the OUTLET ON position. See **Figure 2.** This will deactivate the timer's control of the lamp, but the timer's dial will still show the current time of day. To reactivate the timer's control of the lamp, turn the lamp's switch on and set the timer's master switch to TIMER ON. In case of power failure, reset the time of day as explained in step 2.

**DO NOT PLUG IN MORE THAN THE RATED LOAD (SEE RATINGS).** To find total watts being used: If watts are not marked on the appliance, multiply ampere rating (on nameplate) by 125 volts to determine equivalent watts. For lamps with multiple bulbs, sum wattage on bulbs.

This is a **GROUNDED** device. It has a grounded plug and two grounded outlets.





**Figure 1** Timer is set to turn on at 10:00PM and off at 2:00AM. Timer shows 9:30PM time of day.

## 

Risk of electric shock • Plug directly into an electrical outlet • Do not use in wet locations • Use indoors only • Unplug timer before cleaning • Keep children away	Risk of fire • Do not use to control appliances that contain heating elements (cooking appliances, heaters, irons, etc.) • Do not exceed electrical ratings
--	---

Figure 2 Master Switch - When pushed to "timer on" timer controls appliance. When pushed to "outlet on" the timer acts like an outlet. Timer outlet is always supplying power.

> 15075 Version 3 10.18.2010 www.jascoproducts.com