

Item # 1002 630 375 1001 413 092 1002 556 649 Model # D13106-7PC-B D13106-D D13106-D-B

USE AND CARE GUIDE

BOLINGBROOK DINING CHAIR



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service

8 a.m. - 7 p.m., EST, Monday-Friday
9 a.m. - 6 p.m. EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

Table of Contents

Table of Contents	
Warranty	2
What is Covered	
What is Not Covered	3
Pre-Assembly	4
Planning Assembly	

Hardware Included	4
Dining Chair Package Contents	5
Assembly	6
Care and Cleaning	7

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

7 YEAR FRAME LIMITED WARRANTY/2 YEAR RESIN WEAVE AND 5 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for 7 years and the resin weave for 2 years and fabric for 5 years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use.

In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions

with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-800-986-3460 or visit www.HomeDepot.com/HomeDecorators.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Tools not shown to actual size.



Part	Description	Quantity
AA	M6X20mm Hex bolt	8
BB	M6 washer	8
CC	M6 Hex bolt cap	8
DD	M6-M8 Hex Wrench	1

Pre-Assembly (continued)

DINING CHAIR PACKAGE CONTENTS



Part	Description	Quantity
Α	Left arm panel	1
В	Right arm panel	1
С	Seat panel	1
D	Chair back	1
E	Seat cushion	1


Assembly

Attaching the arm panels

- □ With the assistance of another person, insert the chair back (D) into arm panels (A) and (B).
- Attach arm panels (A) and (B) with back using M6 hex bolts (AA) and M6 washers (BB).
- □ Tighten all M6 hex bolts (AA) with the M6 wrench (DD).
- □ Attach the hex bolt caps (CC).




NOTE: Please ensure all M6 hex bolts (AA) are aligned and assembled correctly. Fully tighten the bolts.




3 Attaching the seat cushion


□ Place the seat cushion (E) onto the chair.



2 Attaching the seat panel and back panel

- Attach the seat panel (C) to chair frame and chair back (D), using M6 hex bolts (AA) and M6 washers (BB).
- □ Tighten all M6 hex bolts (AA) with the M6 wrench (DD).
- □ Attach the hex bolt caps (CC).





Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.






Item # 1002 630 376 1001 413 123 Model # D13106-7PC-B D13106-TT

USE AND CARE GUIDE

BOLINGBROOK DINING TABLE



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday-Friday 9 a.m. - 6 p.m. EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Table of Contents

Table of Contents	
Warranty	2
What is Covered	
What is Not Covered	2
Pre-Assembly	3
Planning Assembly	

Care and Cleaning	6
Assembly	5
Table Package Contents	4
Hardware Included	3

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND THIS WARRANTY DOES NOT APPLY TO COMMERCIAL USE

7 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for 7 years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use.

In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-800-986-3460 or visit www.HomeDepot.com/HomeDecorators.

Pre-assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED




NOTE: Tools not shown to actual size.



Part	Description	Quantity
AA	M6X20mm Hex bolt	16
BB	M6 washer	16
CC	M6 Hex bolt cap	16
DD	M6-M8 Hex Wrench	1

Pre-assembly

TABLE PACKAGE CONTENTS



Part	Description	Quantity
Α	Table top	1
В	Table leg	2
С	Table leg support	2

Assembly


1 Attaching the table legs

- ☐ Place the table top (A) on a soft, flat non-abrasive surface.

 Attach the table legs (B) to the table top (A) with the M6 hex bolts (AA) and washers (BB).
- ☐ Tighten all bolts with the wrench (DD) and attach the bolt caps (CC).



NOTE: Please ensure all M6 hex bolts are assembled correctly and use the M6-M8 wrench (DD) to tighten.




3 Positioning the table

- ☐ With the assistance of another person turn the table over and set it down on its legs.
- \Box The table is now ready for use.



2 Attaching the table leg support

- Attach the table leg support (C) to the table legs (B) using the M6 hex bolts (AA) and washers (BB).
- \Box Tighten all M6 hex bolts (AA) with the M6-M8 wrench (DD).
- \square Attach bolt caps (CC).



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- □ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.