


Wireless Thermometer



Model: T83622v2

DC:092418

Contents

[2. Power Up](#)

[3. LCD Features](#)

[3. Settings Menu](#)

[3. Fahrenheit/Celsius](#)

[4. MIN/MAXTemp Records](#)

[4. Temperature Trend Arrows](#)

[4. Search for Outdoor Sensor](#)

[4. Low Battery Indicator](#)

[4. Factory Restart](#)

[5. Join the Conversation](#)

[5. Sensor Shield](#)

[5. Specifications](#)

[5. Care+ Maintenance](#)

[6. Warranty + Support](#)


[6. FCC Statement](#)

[6. Canada Statement](#)


Power Up

1. Insert 2-AA batteries into your Outdoor Sensor.
2. Insert 2-AA batteries into your station.
3. Set time, date, etc.
4. Once the sensor is reading to your station, place sensor outside in a shaded location.

Watch sensor mounting video: http://bit.ly/TH_SensorMounting



LCD Features



Setting Menu

It is best to press one button at a time when setting the station.

1. Hold the SET/°F/°C button to enter the Settings Menu.
2. Press and release the MIN/MAX/+ button to adjust the values.
Hold to adjust quickly.
3. Press and release the SET/°F/°C button to confirm and move to the next item.

Note: Use one button at a time in Settings Menu.

Settings order:

- 12/24 Hour Time Format
- Hour
- Minutes

Fahrenheit or Celsius

- Press the SET/°F/°C button to select Fahrenheit or Celsius temperature display.

MIN/MAX Temperature Records

The indoor and outdoor MIN/MAX temperature records will reset daily at midnight. This provides a daily 24 hour MIN/MAX reading.

- Press the MIN/MAX/+ button to view minimum and maximum temperatures.
- When viewing minimum and maximum values, hold the MIN/MAX/+ button to reset them to current readings.

Temperature Trend Arrows

- The UP, DOWN and STEADY ARROWS indicate a rising, steady or falling temperature trend (2°F/1°C) over the past three hours.
- Updates every 30 minutes or less.



Search for Outdoor Sensor

- Hold the MIN/MAX/+ button for 3 seconds to search for the outdoor sensor.
- The reception icon will animate until the sensor signal is received or for 3 minutes if no signal available.

Low Battery Indicator

- When low battery shows in Outdoor Temperature section, replace batteries in the outdoor sensor.
- When low battery shows in Indoor Temperature section, replace batteries in the station.

Factory Restart

Explanation: The factory restart returns the temperature station and outdoor sensor to an “out-of-the-box” state and often resolves an issue.

Factory Restart:

1. Remove all power from outdoor sensor and temperature station.
2. Press one of the buttons on the temperature station at least 20 times to clear all memory.
3. Verify that the temperature station is blank before proceeding (there are some painted lines that will not disappear).
4. Leave batteries out of both units for 15 minutes (very important).
5. Insert fresh Alkaline batteries into the temperature station.
6. Insert fresh batteries into the outdoor sensor.
7. Press the TX button on the outdoor sensor to transmit RF signal.
8. Keep the outdoor sensor 5-10 feet from the temperature station.
9. When RF connection is established, the temperature will appear on the station. Allow the outdoor sensor and temperature station to sit together for 15 minutes to establish a strong connection.
10. Do not press buttons for 15 minutes.

Join the Conversation

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



Sensor Shield - not included

- The Sensor Weather Shield is designed to protect your outdoor sensor from rain and snow.
- This shield will offer limited protection from the sun's heat.
- Purchase at: <http://bit.ly/925-1418>



Specifications

Indoor Temperature Range: 32°F to 122°F (0°C to 50°C)

Interval: About every 30 seconds

Outdoor Temperature Range: -40°F to 140°F (-40°C to 60°C)

Interval: About every 50 seconds

Transmission Range: 330 ft (100 meters) open air. 433MHz RF

Power Requirements:

Temperature Station: 2-AA batteries not included

TX141-Bv3 sensor: 2-AA batteries not included

Battery Life:

Temperature Station-over 24 months

Tx141-Bv3 Sensor-over 24 months

Dimensions:

Wireless Thermometer: 3"L x 1.36"W x 4.17"H (7.6 x 3.4 x 10.6 cm)

TX141-Bv3 Sensor: 1.57" x 0.79" x 5.12" (4.0 x 2.0 x 13.0 cm)

Care + Maintenance

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

Warranty + Support

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

Please call our friendly customer support representatives based out of our office in La Crosse, Wisconsin.

Phone: 1.608.782.1610

Our knowledgeable customer support team is available: Monday-Friday, 8am-6pm CST.

For Full Warranty Details, Visit: www.lacrossetechnology.com/support

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

Canada Statement

This device complies with CNR Industry Canada license -exempt devices. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.