



## Operating Instructions for HeatTrak's Wireless Remote Control

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. This device complies with Part 15 of the FCC Rules.



### Operating Instructions:

1. Plug the 2-outlet receiver into any properly grounded outlet that will be used for the HeatTrak mats. Make sure the receiver does not rest on the ground unless it is in a location that is completely covered. A red light will appear when the receiver is properly plugged in to your outlet. If a red light does not appear, then check your outlet to make sure it is working. You can test your outlet by plugging another item into it such as a radio or portable fan.
2. Plug the HeatTrak heating mats into any or both of the outlets on the receiver.
3. Control the mats by pressing the "On" or "Off" buttons on the controller key chain. By pressing the "ON" button, the red light on the receiver will turn to green indicating that the heating mats are on. When you press the "OFF" button, your receiver will turn back to red indicating that your mats are off. If the light does not turn green when pressing the "ON" button, the battery in the controller keychain may need to be replaced.
4. It is recommended to turn your mats on at least an hour before any expected snow fall and to keep your mats on for a few hours after the snow has stopped.

**NOTE:** If the green light does not turn on when pressing the "ON" button, the batteries may need replacing. It is possible that the battery may need replacing every year, especially if the controller has not been used for many months.

**BATTERY INFORMATION & REPLACEMENT:** The Remote Control uses a 3-Volt CR2032 lithium battery. To replace, unscrew the battery cover on the back of the key chain controller. Insert a new CR2032 lithium battery, making sure to match up the + and – markings. To test, press the ON or OFF buttons to make sure the LED lights up.

HeatTrak LLC  
255 E 17<sup>th</sup> Street  
Paterson, NJ 07524  
[www.HeatTrak.com](http://www.HeatTrak.com)