
Parts & features

1 Measuring cup	6 Drive clutch	1 Personal jar seal
② Jar lid	Top housing pad	(12) Personal jar assembly
③ Jar seal	8 Main Unit	(13) Personal jar seal
④ Temper	9 Rubber feet	(14) Personal jar cover
(5) Jar	1 Personal jar	(15) Seal cover
Control nanol		

Control panel

3



- 1. STOP : When knob set at 0, the machine stop and not operate.
- 2. **1 2 3**: 1, 2, 3 are low/middle/high speed.
- 3. **Pulse:** Set the knob at any position instead of 0, push pulse button the machine will operate at high speed. Release the button the machine stop.
- 4. 📓 : Set the knob here, the machine operate 1 second On, 4 seconds off, repeat this for 12 cycles, then auto stop, total 1 minute.
- 5. \oint : Set the knob here, the machine speed increase gradually to high for 0~10s, keep high speed for rest 50s, then auto stop, total 1 minute.