Cycle Guide

O = Available option

							O = /\tvaliable option			
Cycle	Fabric Type	Dry Level	Temperature	Time in Min.	More Time/ Less Time	Wrinkle Care	Damp Dry Signal	Reduce Static	Easy Iron	
Steam Fresh™	Comforter, shirts, trouser (except especially delicate fabrics)	OFF	MID HIGH	20	- 0	0		0	0	
			ADJUSTABLE	ADJUSTABLE						
Steam Sanitary [™]	Comforter, bedding, children' clothing	OFF	HIGH	39		0				
Anti Bacterial	Do not use this cycle with delicate fabrics.	VERY	HIGH	70		0				
Wool	Wool Fabric	NORMAL	ULTRA LOW	26		0				
Spot Clean™	Shirt	OFF	HIGH	22		0				
Jumbo Dry	Comforters, pillows, shirt	NORMAL	MEDIUM	85		0				
		ADJUSTABLE								
Perm. Press	Permanent press, synthetic items	NORMAL	LOW	32		0	0	0	0	
		ADJUSTABLE								
Cotton/ Normal	Work clothes, corduroys, etc.	NORMAL	MEDIUM	41		0	0	0	0	
		ADJUSTABLE								
Heavy Duty	Jeans, heavyweight items	NORMAL	HIGH	54		0	0	0	0	
		ADJUSTABLE								
Delicates	Lingerie, sheets, blouses	NORMAL	LOW	28		0	0	0	0	
		ADJUSTABLE								
Towels	Denims, towels, heavy cottons	NORMAL	MID HIGH	55		0	0	0	0	
		ADJUSTABLE								
Speed Dry	For small loads with short drying times	OFF	HIGH	25	0	0		0	0	
			ADJUSTABLE	ADJUSTABLE						
Air Dry	For items that require heat-free drying such as plastics or foam filled items	OFF	NO HEAT	30	- 0	0				
				ADJUSTABLE						
Super Dry	Work clothes, corduroys, etc.	VERY	HIGH	59		0				

Sensor dry cycles

Sensor dry cycles utilize LG's unique dual sensor system to detect and compare the moisture level in clothes and in the air and adjust the drying time as needed to ensure superior results. The dryer automatically sets the dryness level and temperature at the recommended setting for each cycle. The estimated time remaining will be shown in the display.



To protect your garments not every dryness level, temperature, or option is available with every cycle. See the **Cycle Guide** for details.

Manual dry cycles

Use manual dry cycles to select a specific amount of drying time and a drying temperature. When a manual dry cycle is selected, the Estimated Time Remaining display shows the actual time remaining in your cycle. You can change the actual time in the cycle by pressing More Time or Less Time.

(NSF.) CERTIFIED BY NSF/P154

NSF International (formerly the National Sanitation Foundation), certifies that the **Anti Bacterial** cycle reduces 99.9% of bacteria on laundry, and none of the bacteria will carry over onto the next laundry load.

- The default settings for the **Anti Bacterial** cycle are **High** temperature and **Very Dry**.
- These default settings cannot be changed.
- Do NOT use this cycle with delicate items or fabrics.