

UHL201R&UHL201H

UNDERHOOD LIGHT SERIES User Manual

PATENT
PENDING



UHL201R

2000lm rechargeable LED underhood light

- SMD LED
- 1000/2000 lumen (step 1/2)
- 4h/2h operating time (step 1/2)
- 3-4h charging time
- 7.4V 5200mAh Li-ion detachable battery pack × 2
- 8.4V 2.4A charger

UHL201H

2000lm rechargeable & corded LED underhood light

- SMD LED
- 1000/2000 lumen (step 1/2)
- 4h/2h operating time (step 1/2)
- 3-4h charging time
- 7.4V 5200mAh Li-ion battery
- 5m 18/2 SJTOW cable
- 8.4V 2.4A charger



bar extends from 47" to 79"



detachable battery pack for charging



detachable bracket



360° swivel light



dual fuel system



tough and ergonomic handle



APPENDIX OPTIONAL ACCESSORIES (Not Included)



ACS301F

heavy duty tri-pod stand
Adjustable height from 4.4' to 9.85'
Use with ACS201P to hang the Underhood Light Series



ACS181W

heavy duty tri-pod wheel stand
3 durable wheels for portable and flexible use
Adjustable height from 2.4' up to 6'
Use with ACS201P to hang the Underhood Light Series



ACS201P

multi-functional fasteners pair
Use with ACS301F/ACS181W to hang the Underhood Light Series



UHL201R&UHL201H

The Underhood Light Series are versatile lights for use in automotive repair, construction, industrial and many other applications. These SMD LED lights provide 75% more luminescence compared to traditional fluorescent lights.

Multi-functional Design

- Bar extends from 47" to 79"
- Coated brackets prevent scratches on car surfaces
- Detachable battery pack for charging (for model UHL201R)
- Light can swivel 360 degree on the bracket
- Drop impact resistant
- The light will flash as a low power warning prior to the battery running out

Brightness Memory Function

- Setting is recorded after 5 seconds of activation
- Recorded setting is recalled next time the device is activated

Dual Fuel System (for model UHL201H)

- Use with cable or rechargeable Li-ion battery

Using Instructions

- Before using assemble two hooks to each side of the bar by supplied hexagon wrench, make sure the screw is locked firmly.
- Plug the charger into any 100-240V AC standard power source to let the unit fully charged until the green indicator on the charger light on.
- Press the switch continuously for changing steps of light sources (cyclic steps: dim-bright-off).

Replace the battery pack for UHL201R:

- Simply press the button on the handle and pull out the battery pack, replace another one and push it back, you will hear a click sound means it successfully attached.

Warnings and Cautions

- Please read and understand this instruction carefully to ensure the safe and effective use of this light. And follow all directions before using.
- Risk of electrical shock, do not use in the environment with gas, combustible or explosive materials, hot objects.
- Keep away from the reach of children.
- Do not open, repair or modify.
- Do not use the light with wet hand.
- Use only under the recommended voltage and frequency requirements.
- To avoid the harm to your eyes, please do not look straight to the light.
- Minimum distance from lighted objects 0.1m.
- Please use correct charger to charge the light.
- The specification in this manual is based on standard lab testing, different environment may influence the data.
- Charge this light every 3months if not in constant using, and after each use, if it is used often to ensure longevity.
- Replace the battery with manufacture and battery designation only.

Warranty

Warranty for 2 years from the original purchase date.

THIS WARRANTY DOSE NOT COVER BATTERY OR ACCESSORIES NOR DEFECTS OR DAMAGES TO THE LIGHT (I) after the warranty period expires; (II) resulting from misuse or abnormal operation; (III) resulting from a failure to properly maintain or operate the tool; or (IV) resulting from any repair or maintenance services performed by any party other than ALS.