



Intelligent Design™

Model: ECD16

- (1) Seat
- (1) Back
- (2) Front legs
- (2) Back legs
- (2) Arms
- (2) Braces
- (1) Hardware pack


TOOLS NEEDED



7/16 Wrench
4mm HEX KEY, ALLEN, T-HANDLE
(INCLUDED)


Step 1

Lay seat on its side. Attach front leg and back leg to seat. Now flip seat around and do the other side. Uses (8) 1-7/8" bolts, nuts and washer



Step 2


Attach arms to front leg using (2) 2-1/4" bolts, nuts and washer



Step 3


Attach back to seat using (2) .27x2" wafer screws

Attach back to rear leg using (2) .27x3" screws



Step 4

Attach braces to legs using (4) .27x2" wafer screws



Qty. Description


6 A-.27 X 2 SOCKET WAFER A



2 B-.27 X 3 SOCKET WAFER A




8 C-1/4-20 X 1-7/8 WAFER SHCS



2 D-1/4-20 X 2-1/4 WAFER SHCS



10 E-1/4 FLAT WASHER



10 F-1/4-20 NYLOCK NUT

