


ATOMIC DIGITAL WALL CLOCK
with Indoor/Outdoor Temp
QUICK START GUIDE



Model: WS-8115U
DC:050818

ATOMIC DIGITAL WALL CLOCK OVERVIEW



POWER UP

1. Insert **2-AAA** batteries into the outdoor sensor.
2. Insert **2-AA** batteries into the clock.
3. Configure basic settings.
4. Once the sensor is reading to your clock, place it outside in a shaded location.

Watch sensor mounting video: http://bit.ly/TH_SensorMounting

SETTINGS

- Hold the **SET** button to enter the Settings Menu.
- Press the **PLUS** button to adjust values.
- Press the **SET** button to confirm and move to the next item or exit.

Settings Menu Order:

1. Time Zone
2. Daylight Saving Time ON/OFF
3. Language
4. Hour
5. Minutes
6. Year (2 digit)
7. Month
8. Date
9. Weekday
10. 12/24 Hour Format
11. Fahrenheit/Celsius

Languages:	
US	English
F	French
E	Spanish
d	German

This clock can be set to time zone +/- 12 or anywhere in between.

North American time zones:
-4h ATL - Atlantic
-5h EST - Eastern (default)
-6h CST - Central
-7h MST - Mountain
-8h PST - Pacific
-9h ALA - Alaska
-10h -Hawaiian

WWVB ATOMIC TIME SIGNAL

- The WWVB Atomic Time Indicator will flash when searching for the signal.
- Depending on your location reception may take up to 5 nights.
- When WWVB signal is received, the indicator will be solid.
- For information about WWVB Atomic time visit: <http://bit.ly/AtomicTime>

ALARM SETTING ((●))

- Hold the **ALARM** button to enter Alarm Settings.
- Press the **PLUS** button to adjust values.
- Press the **ALARM** button to confirm and move to the next item or exit.

ACTIVATE | DEACTIVATE ALARM

- Press the **ALARM** button to activate or deactivate the alarm.
 - The Alarm Indicator will display when active.
- Note:** The alarm will automatically be activated after setting a new alarm time.

SNOOZE

- When the alarm sounds, press the **SNOOZE** button to silence the alarm for 10 minutes. The Alarm Indicator will flash.
- This is a crescendo alarm that will sound for 120 seconds if not deactivated.

POSITIONING YOUR SENSOR

- Mount the outdoor sensor on a north-facing wall or in any well shaded area. Under an eave or deck rail is preferred.
- The maximum transmitting range to the clock is over 200 feet (60 meters) in open air, not including walls.

POSITIONING YOUR CLOCK

- Use the Mounting Hole for placement on a wall.
- Use the Pull Out Legs to freely position on a table.

RESET BUTTON

- If your clock is not responding to button presses, use a pen or paper-clip to press the RESET button one time.
- This should reset the clock back to its default settings.

LOW BATTERY INDICATORS

TX

RX

- When the TX battery indicator is displayed replace batteries in the outdoor sensor.
- When the RX battery indicator is displayed replace batteries in the atomic clock.

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



WE'RE HERE TO HELP!

Our knowledgeable customer support team is available: Monday-Friday, 8am-6pm CST.

Phone: 1.608.782.1610

SPECIFICATIONS

Indoor:

Temperature Range: 14.2°F to 99.9°F (-9.9°C to 37.7°C)

Outdoor:

Temperature Range: -39.8°F to 139.8°F (-39.9°C to 59.9°C)

Distance: Over 200 ft. (60 meters) RF 915MHz (open air)

Interval: About every 8 seconds

Power:

Atomic Clock 2-AA, IEC, LR6 batteries (not included)
TX38U-IT-N Sensor: 2-AAA, IEC, LR3 batteries (not included)

Battery Life:

Atomic Clock Over 24 months
TX38U-IT-N Sensor: Over 12 months

Dimensions:

Atomic Clock: 8.9"L x 1.2"W x 7.1"H
(22.60 L x 3.04W x 18.03 H cm)
TX38U-IT-N Sensor: 1.28"L x 0.56"W x 3.41"H
(3.25 L x 1.42 W x 8.66 cm)

WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

For Full Warranty Details, Visit: www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

CANADA STATEMENT

This device complies with CNR Industry Canada license -exempt devices.

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

⚠ WARNING: This product can expose you to chemicals including styrene, which is known in the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.