

LIGHTBOLT MAX EXTENDABLE WORK LIGHT

Model No. 4063

INSTRUCTION MANUAL

MobilePower, LLC. Miami, FL www.mobilepower-us.com Customer Support: (800) 708-8550 customerservice@mobilepower-us.com BEFORE YOU USE THIS DEVICE FOR THE FIRST TIME, PLEASE READ THE FOLLOWING NOTES IN THIS MANUAL AND HEED ALL WARNINGS AND CAUTIONS, EVEN IF YOU ARE FAMILIAR WITH HANDLING ELECTRONIC DEVICES. KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE.

WARNING

To prevent serious injury or damage:

- Keep dry. DO NOT open, drop, short-circuit, incinerate, expose temperatures higher than 140°F, or change /use if damaged.
- Only use the Charging Adaptors provided with the Work Light. Use of any other adaptors may damage the tool or result in a fire.
- Do not submerge in water or any other liquid. It is not waterproof.
- Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.
- Do not charge the Work Light more than 8 hours. Overcharging will cause overheating and shorten battery life.
- Read warnings on the package before use.

PRODUCT DESCRIPTION

Your new cordless rechargeable Extendable Work Light provides a safe and portable source of light when and where you need it. It is not waterproof and prolonged use in the rain or snow should be avoided.

It is ideal to use during automotive repair work, roadside emergencies, work around the home, camping, or during power failures.

Power Requirements 6V DC 500mA

Battery Type Internal, Rechargeable, Lithium-ion

 Battery Pack
 3.7 V 2000mAh

 Bulb Type
 Red & White LEDs

 LED Life
 100,000 Hours

 USB Output
 5 V DC / 1A

RUNNING TIME

The approximate running time for this light when the battery is fully charged and at maximum performance level are as following:

MAGNETIC BASE

The Extendable Work Light features a magnetic base with a soft coating on the bottom, allowing the light to be attached to a vehicle or other metal objects without damaging or scratching the painted surface.

NOTE: Do not place the light on or near computer equipment, computer disks or other types of magnetic storage equipment as strong magnetic fields can erase or corrupt data.

OPERATION MODES

This extendable work light features 5 different light modes. You can select the suitable light operation mode for each application.

1. SPOTLIGHT

Press the Power Switch once while the unit is retracted (position I). In this mode the Extendable Work Light operates as a spotlight using 1W LED, this gives a powerful focused light with a maximum operating time of at least 6 hours on a full charge.

Press the Power Switch twice to turn ON the red flashlight LEDs on top of the unit, to turn OFF, press the Power button once again.

Note: The spotlight will turn off when the extendable work light section is opened (Position I).

2. WORK LIGHT

Hold the light by the main body and pull the lens section upwards to open the unit (Position I), in this mode, the Lightbolt Max can be operated as a work light using 30 SMD LEDs for maximum illumination (High Mode). Operating time in this mode is up to 3 hours on a full charge.

Press the Power Switch once for low mode. Operating time in this mode is up to 6 hours on a full charge.

LIGHTING MODES

The Lightbolt Max can operate in 5 different modes while the unit is in the extended position:

- Work Light (High)
 Comes ON when the unit is extended to position (I)
- Work Light (Low)
 Press the power switch once while the unit is extended to position (I)
- Work Light (High) + 1W Spot Light:

- Press the power switch twice while the unit is extended to position (I)
- Top & Side Red Flashing LED's:
 - Press the power switch three times while the unit is extended to position (I)
- Work Light + 1W Spot Light + Top & Side Red flashing LEDs:
 Press the power switch four times while the unit is extended to position (I)

 Note: to turn the unit OFF, press the power switch five times.


USB CHARGING PORT

The Lightbolt Max has a built-in USB charging port output to recharge small portable USB devices.

- 1. Plug the device's USB cable into the USB port located on the base of the unit.
- Press the Power Button next to the USB port, (the LED power indicator light will turn ON) and the charging process will begin (the LED indicator will turn off automatically after 5 seconds but the charging process will continue).
- 3. Disconnect the device's USB charging cable from the Lightbolt Max when the charging is completed.

Note:

- The USB LED power indicator and power output will be disabled after 10 seconds if a USB device is not connected to the unit's USB port.
- 2. To turn OFF the Lightbolt Max USB power output, press the USB power button for 3 seconds.



CHARGING INSTRUCTIONS

THE EXTENDABLE WORK LIGHT MUST BE FULLY CHARGED BEFORE BEING USED FOR THE FIRST TIME. IT IS RECOMMENDED THAT THE BATTERY BE RE-CHARGED EVERY 3 MONTHS TO ENSURE MAXIMUM PERFORMANCE IN AN EMERGENCY.

This will ensure that the battery gives its best performance now and on future re-charging cycles. The AC and DC charging adapters are for recharging the battery only. They cannot be used to directly power the light. Always ensure that the light switch is in the OFF position while charging.

USING THE AC CHARGING ADAPTER:

- 1. Stand the light vertically on its base. Plug the AC charger into the charging port on the base of the unit next to the charging LED indicator.
- 2. Plug the adapter into a 120V outlet and switch ON the outlet (if applicable).
- 3. The charging indicator LED will glow RED while charging is in progress.
- 4. The battery will be fully charged after approximately 4-6 hours, and the RED charging indicator will turn GREEN when the unit is fully charged. Disconnect the AC charger from the light and remove the adapter from the wall outlet.

TO PREVENT OVERHEATING DO NOT CHARGE FOR MORE THAN 8 HOURS.

SAFETY PRECAUTIONS

Use the 120V AC charging adapter indoors in a dry location only. Exposure to damp or wet conditions could cause a shock or damage to the adapter.

Do not use the charger near flammable liquids or materials.

Store in dry location and do not allow the charging adapter to come in contact with water, rain or snow.

If the charging adapter comes into contact with water, place in a dry location at room temperature, on a soft absorbent towel and allow to dry thoroughly.

Do not operate the unit until it is completely free of moisture.

Use only the AC charging adapter supplied with light. Do not attempt to charge the light with an adapter that is not compatible as this could result in a fire, damage to the light or personal injury.

The AC CHARGING ADAPTER complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

USING THE AC CHARGING ADAPTER:

- Stand the light vertically on its base. Plug the AC charger into the charging port on the base of the unit next to the charging LED indicator.
- 2. Plug the adapter into a 120V outlet and switch ON the outlet (if applicable).
- 3. The charging indicator LED will glow RED while charging is in progress.
- 4. The battery will be fully charged after approximately 4-6 hours, and the RED charging indicator will turn GREEN when the unit is fully charged. Disconnect the AC charger from the light and remove the adapter from the wall outlet.

TO PREVENT OVERHEATING DO NOT CHARGE FOR MORE THAN 8 HOURS.

USING THE DC CHARGING ADAPTER

- 1. Stand the light vertically on its base. Plug the adapter's jack into the socket on the base of the light next to the charging LED indicator.
- 2. Plug the adapter into the vehicle's 12V DC cigarette lighter or accessory power socket.
- 3. The charging indicator LED will glow RED while charging is in process.
- 4. The battery will be fully charged after approximately 10 hours, and the RED charging indicator will turn GREEN when the unit is fully charged.
- 5. Disconnect the charging jack from the light and remove the DC adapter from the 12VDC socket.

TO PREVENT OVERHEATING DO NOT CHARGE FOR MORE THAN 12 HOURS.

SAFETY PRECAUTIONS

The DC charging adapter can be used in most vehicles by plugging into the 12V DC cigarette lighter or accessory power socket.

Store in dry location and do not allow the charging adapter to come in contact with water, rain or snow.

If the charging adapter comes into contact with water, place in a dry location at room temperature, on a soft absorbent towel and allow too dry thoroughly.

Do not operate the unit until it is completely free of moisture.

Use only the DC charging adapter supplied with this light. Do not attempt to charge the light with an adapter that is not compatible as this could result a fire, damage to the light or personal injury.

CARE AND MAINTENANCE STORAGE

Store the Extendable Work Light and charging adapters in a clean and dry area. Be sure to keep the charging adapters supplied with this product stored separately from similar items as only charging adapters included with this light are compatible. Using a non-compatible charger could cause damage to the light or personal injury.

The work light may also be stored in a vehicle for use in roadside emergencies. To prevent the light and any of the accessories from being damaged, please ensure that it is properly secure and in a safe place inside the vehicle.

CLEANING

All exterior surfaces of the Extendable Work Light can be wiped clean with a soft cloth dampened with a mild soap and water solution. Do not immerse or submerge any part of light in water or any other solvent. Never use solvents or cleaning agents containing petroleum (petrol, kerosene, oil), paint thinner, turpentine, alcohol, or ammonia. Harsh materials like these can damage surfaces.

MAINTENANCE

Only qualified service personnel must perform repairs. Do not open the exterior casing of the Extendable Work Light as there are no user serviceable parts inside. Opening or visible attempts to open or repair a light may void any guarantee and / or cause damage to the product or personal injury. LED bulbs will never wear out under normal conditions and do not need to be replaced. Rechargeable battery pack cannot be replaced.





This product contains an internal Lithium-ion battery pack formulated from environmentally sensitive materials. This product must be disposed of properly with due care for the environment. Please return this product to your local dealer or to your local recycling station where batteries will be recycled or disposed of properly.

MobilePower, LLC. Warrants to the original purchaser that this portable lighting unit shall be free from defects in material and workmanship for a period of one year from the original date of purchase. If the product is determined by MobilePower, LLC to be defective in material and workmanship during the warranty period MobilePower, LLC will repair or replace the defective product or defective accessories/components with factory original specification product at its option. The original purchaser is authorized to obtain this warranty with the proof of purchase within the warranty period. To obtain shipping instructions related to the warranty services in North America visit us at www.mobile power-us.com, call 800-708-8550 Customer Support or contact us at customerservice@ mobilepower-us.com.

You may ship the defective product with freight prepaid to MobilePower, LLC. Your replacement will be shipped back to you at no additional charge.

Great care must be taken when packing the product and all associated accessories into a suitable packing box along with the original dated purchase receipt or invoice. The package must include a letter stating the defect details, contact information including physical address. Any address with a PO Box will not be processed and will be held until further notification from the consumer.

Make certain that your package can be tracked when you are shipping the defective products to us. MobilePower, LLC will not be responsible for lost packages sent by consumers. MobilePower, LLC. Will not be responsible for damages incurred during shipment to our facilities. Failure to provide the original purchase receipt or proof of purchase will render this warranty invalid.

THIS WARRANTY SHALL NOT APPLY IF THIS PRODUCT IS: (A) DAMAGED RESULTING FROM ABUSE, MISUSE, NEGLIGENCE, ACCIDENT, LACK OF MAINTENANCE, ABNORMAL WEAR AND TEAR, UNREASONABLE USE OR BY OTHER CAUSES UNRELATED TO DEFECTIVE MATERIAL OR WORKMANSHIP (B) IS USED FOR COMMERCIAL PURPOSES; (C) IF THE PRODUCT HAS BEEN SUBJECTED TO WATER OR FIRE.

This warranty provides you with specific legal rights, and you may also have other rights which vary from state to state.



This warranty is valid only in North America.



MobilePower, LLC. Miami, FL www.mobilepower-us.com Customer Support: (800) 708-8550 customerservice@mobilepower-us.com