



# PARTS INCLUDED:




(A) Seat




(B) Front Leg




(C) Rear Armrest Support




(D) Arm Rest



(E) Back Rest



4 PC Barrels  
10 PC Nuts



2 PC Long Machine Thread (6 x 60 m/m)  
8 PC Short Machine Thread (6 x 50 m/m)  
4 PC Lag Bolts (6 x 60 m/m)  
4 PC Wood Screws (3.5 x 40 m/m)

## ITEM# 4617 - How To Assemble Your Adirondack Chair

**TOOLS NEEDED:** Philips screwdriver, power drill optional

**CAUTION:** When assembling chair, **DO NOT** completely tighten the bolts and nuts until all the parts & holes are properly aligned.


### Step 1:

Place (A) Seat on its side and screw (B) Front Leg with three Short Machine Thread (6 x 50 m/m) and three Nuts.

Repeat on the other side.

3 PC Short Machine Thread (6 x 50 m/m) & 3 Nuts


3 PC Short Machine Thread (6 x 50 m/m) & 3 Nuts



### Step 2:

Place (A) Seat in upright position. Screw (C) Rear Armrest Support with one Short Machine Thread (6 x 50 m/m) and one Nut to (A) Seat so that it is perpendicular to the floor. Repeat on the other side.

1 PC Short Machine Thread (6 x 50 m/m) & 1 Nut




1 PC Short Machine Thread (6 x 50 m/m) & 1 Nut

**NOTE:** Lightly screw the bolts of (C) Rear Armrest Support to properly attach to (D) Armrest in the next step.

### Step 3:

Attach the back of (D) Armrest to (C) Rear Armrest Support with one Long Machine Thread (6 x 60 m/m) and one Nut. Repeat on the other side. Push (D) Armrest forward until it hits the wings of (B) Front Leg and use two short Wood Screws (3.5 x 40 m/m) to attach them together. Repeat on the other side.



### Step 4:

Place two barrels into the holes found on the bottom frame of the Back Rest (E) and two barrels into holes found at the inner side of (C) Rear Armrest Supports. Position (E) Back Rest onto (C) Rear Armrest Supports. Use one Lag Bolt (6 x 60 m/m) to attach the bottom of (E) Back Rest to (A) Seat on each side. Lastly, screw the remaining Lag Bolts (6 x 60 m/m) to attach (E) Back Rest to the top of (C) Rear Armrest Support of each side.

